

**TRANSIMS:
TRansportation ANalysis SIMulation System**

Version: TRANSIMS-LANL - 3.1

**VOLUME FIVE—SOFTWARE: INTERFACE
FUNCTIONS AND DATA STRUCTURES**

31 August 2004

LA-UR-00-1755

Los Alamos
NATIONAL LABORATORY

Copyright © 2004, The Regents of the University of California. This software was produced under a U.S. Government contract (W-7405-ENG-36) by Los Alamos National Laboratory, which is operated by the University of California for the U.S. Department of Energy. The U.S. Government is licensed to use, reproduce, and distribute this software. Neither the Government nor the University makes any warranty, express or implied, or assumes any liability or responsibility for the use of this software.

VOLUME FIVE—SOFTWARE: INTERFACE FUNCTIONS AND DATA STRUCTURES

31 August 2004

The following individuals contributed to this document:

C. L. Barrett*
R. J. Beckman*
K. P. Berkbigler*
K. R. Bisset*
B. W. Bush*
K. Campbell*
S. Eubank*
K. M. Henson*
J. M. Hurford*
D. A. Kubicek*
M. V. Marathe*
P. R. Romero*
J. P. Smith*
L. L. Smith*
P. L. Speckman**
P. E. Stretz*
G. L. Thayer*
E. Van Eeckhout*
M. D. Williams*

* Los Alamos National Laboratory, Los Alamos, NM 87545

** National Institute of Statistical Sciences, Research Triangle Park, NC

Acknowledgments

This work was supported by the U. S. Department of Transportation (Assistant Secretary for Transportation Policy, Federal Highway Administration, Federal Transit Administration), the U.S. Environmental Protection Agency, and the U.S. Department of Energy as part of the Travel Model Improvement Program.

Volume Five: Contents

1. SYNTHETIC POPULATION	1
1.1 INTERFACE FUNCTIONS.....	1
1.2 DATA STRUCTURES.....	7
2. ACTIVITIES.....	9
2.1 INTERFACE FUNCTIONS.....	9
2.2 DATA STRUCTURES.....	21
3. VEHICLE.....	31
3.1 INTERFACE FUNCTIONS.....	31
3.2 DATA STRUCTURES.....	34
3.3 FILES	36
4. VEHICLE PROTOTYPES	37
4.1 INTERFACE FUNCTIONS.....	37
4.2 DATA STRUCTURES.....	39
4.3 FILES	40
5. PLAN.....	41
5.1 INTERFACE FUNCTIONS.....	41
5.2 DATA STRUCTURES.....	47
6. ITERATION DATABASE.....	49
6.1 INTERFACE FUNCTIONS.....	49
6.2 DATA STRUCTURES.....	59
7. SIMULATION OUTPUT	61
7.1 INTERFACE FUNCTIONS.....	61
7.2 DATA STRUCTURES.....	75
8. TRANSIT	84
8.1 INTERFACE FUNCTIONS.....	84
8.2 DATA STRUCTURES.....	87
9. NETWORK	89
9.1 INTERFACE FUNCTIONS.....	89
9.2 DATA STRUCTURES.....	103
10. INDEXING	118
10.1 INTERFACE FUNCTIONS.....	118
10.2 DATA STRUCTURES.....	126
10.3 UTILITY PROGRAMS.....	129
10.4 FILES	132
10.5 USAGE	132
10.6 EXAMPLES.....	134
11. CONFIGURATION	136
11.1 INTERFACE FUNCTIONS.....	136

11.2	DATA STRUCTURES.....	137
11.3	UTILITY PROGRAMS	137
11.4	FILES	137
11.5	CONFIGURATION FILE KEYS.....	138
11.6	EXAMPLES.....	138
12.	LOGGING	145
12.1	INTERFACE FUNCTIONS.....	145
12.2	FILES	146
12.3	EXAMPLES.....	146
VOLUME FIVE: INDEX.....		147

Volume Five: Tables

Table 1:	Vehicle library files.....	36
Table 2:	Vehicle Prototype library files.....	40
Table 3:	Indexing library files.....	132
Table 4:	Indexes used by TRANSIMS components.....	132
Table 5:	Configuration library files.	137
Table 6:	Logging library files.....	146

1. SYNTHETIC POPULATION

1.1 Interface Functions

The synthetic population subsystem has C structures and utility functions that are used to read and write synthetic population data from TRANSIMS synthetic population files.

1.1.1 moreSyntheticHH

Signature int moreSyntheticHH (FILE* const fp)

Description Boolean function used to control iteration through the synthetic population file.

Argument fp – the FILE* pointer for the synthetic population file that must be open for reading.

Return Value 1 if not at end of synthetic population file.
0 if EOF has been reached.

1.1.2 getNextSyntheticHH

Signature const SyntheticHHData* getNextSyntheticHH (FILE* const fp)

Description Reads a synthetic household from the synthetic population file. Parses and converts the values from the file and stores them in the static SyntheticHHData structure.

Argument fp – the FILE* pointer for the synthetic population file that must be open for reading.

Return Value The address of a static SyntheticHHData structure containing the data read from the file.
NULL on error.

1.1.3 **writeSyntheticPopHeader**

Signature `int writeSyntheticPopHeader (FILE* const fp,
 char* hh_header, char* p_header)`

Description Writes the header lines in the synthetic population file.

The format of the line is:

<text>: <demog1> <demog2> ... <demogN>

Example:

```
Household Demographics: PUMSHH R18UNDR RWRKR89  
RHHINC Person Demographics: AGE RELAT1 SEX WORK89
```

Argument `fp` – the `FILE*` pointer to synthetic population file that must be open for writing with the file pointer positioned at the beginning of the file.

`hh_header` – the string containing the household header information.

`p_header` – the string containing the person header information.

Return Value 1 on success.
 0 on error.

1.1.4 **CreatePopulationIndex**

Signature `int CreatePopulationIndex (const char* popFileName)`

Description Creates an index to a TRANSIMS synthetic population file sorted by home location as the primary key, and household ID as the secondary key.

Argument `popFileName` – the name of the TRANSIMS synthetic population file.

Return Value 1 on success.
 0 on error.

1.1.5 **getSyntheticHHFromString**

Signature `const SyntheticHHData* getSyntheticHHFromString (const char* data)`

Description Reads and parses the data for a `SyntheticHHData` record from a data string. The data string may not be null terminated.

Argument `data` – the data character string.

Return Value The address of a static `SyntheticHHData` structure containing the data read from the string.
NULL on error.

1.1.6 **writeSyntheticHH**

Signature `int writeSyntheticHH (FILE* const fp,
const SyntheticHHData* hh)`

Description Writes the given `SyntheticHHData` into the given synthetic population file.

Argument `fp` – the `FILE*` pointer to the synthetic population file that must be open for writing.
`data` – the address of a `SyntheticHHData` structure containing the data to be written.

Return Value 1 on success.
0 on error.

1.1.7 `getSyntheticHouseholdFromIndex`

Signature `const SyntheticHHData* getSyntheticHouseholdFromIndex(BTree* index, BTreeEntry* key)`

Description Get the data for the household from an indexed file.

Argument `index` – `BTree*` – a BTree index for the synthetic population data that is indexed by household ID.
`key` – `BTreeEntry*` – a BTreeEntry structure that contains the household ID as the first key.

Return Value A pointer to a static `const SyntheticHHData` structure on success.
0 on error.

1.1.8 `getSyntheticPopDemographicHeaders`

Signature `int getSyntheticPopDemographicHeaders(FILE* const fp, const char** hh_header, const char** person_header)`

Description Reads a character array that holds the headers for both the household demographics and the person demographics. The headers are stored in the `hh_header` and `person_header` character arrays.

Argument `fp` – the `FILE*` pointer to the synthetic population. Must be open for reading.

Outputs `hh_header` – the address of a character array that holds the headers for the household demographics.
`person_header` – the address of a character array that holds the headers for the person demographics.

Return Value 1 on success.
0 on error.

1.1.9 CreateDoublePopulationIndex

Signature void **CreateDoublePopulationIndex** (const char* filename,
int field_pos1, enum act_key_types field_type1,
int field_pos2, enum act_key_types field_type2,
const char*extension1, const char*extension2,
int headerLines)

Description Creates two indexes where the first primary index is field position 1 (*.extension1), the first secondary index is field position 2, the second primary index is field position 2 (*.extension2), and the second secondary index is field position 1 from the data file.

Argument filename – the name of the data file to be indexed.
field_pos1 – the position of the field to be used for the first index.
field_type1 – the type of the first field (i.e., kTypeInt for an integer field.)
field_pos2 – the position of the second field to be used for the second index.
field_type2 – the type of the second field (i.e., kTypeFloat for a floating-point field.)
extension1 – the extension for the first index (i.e., *hh.idx*).
extension2 – the extension for the second index (i.e., *trv.idx*).
headerLines – the number of header lines in a population file.

Return Value None.

1.1.10 **CreatePopIndexFromFile**

Signature `BTree* CreatePopIndexFromFile (const char* data_file),
 const char* index_file, int fieldPos1,
 enum act_key_types keyType1, int fieldPos2,
 enum act_key_types keyType2)`

Description Creates a population index from a data file.

Argument `data_file` – the file to be indexed.
`index_file` – the index file.
`fieldPos1` – the position of the field to be used for the first index.
`keyType1` – the type of the first field (i.e., `kTypeInt` for an integer field).
`fieldPos2` – the position of the field to be used for the second index.
`keyType2` – the type of the second field (i.e., `kTypeInt` for an integer field).
`extension2` – the extension for the second index (i.e., `trv.idx`).
`headerLines` – the number of header lines in a population file.

Return Value None.

1.2 Data Structures

1.2.1 SyntheticPersonData

This structure is used to hold synthetic person information.

```
typedef struct synPersonData_s
{
    /** TRANSIMS Person ID. */
    INT32 fPersonID;

    /** Array of person demographic information. */
    INT32 *fPersonDemographics;

} SyntheticPersonData;
```

1.2.2 SyntheticHHData

This structure is used to hold synthetic household information.

```
typedef struct synHHdata_s
{
    /** The Census Tract ID of the household. */
    INT32 fTract;

    /** The Block Group ID of the household. */
    INT32 fBlockGroupID;

    /** The TRANSIMS Household ID. */
    INT32 fHHId;

    /** The number of persons in the household. */
    int fNumberPersons;

    /** The number of vehicles owned by the household. */
    int fNumberVehicles;

    /** The home location of the household - a TRANSIMS activity
     *  location ID.
     */
    INT32 fHomeLocation;

    /** Number of data items in the household
     *  demographics/data array. */
    int fNumberHHDemographics;
```

```
/** Array of household demographic/data information. **/
REAL *fHHDemographics;

/** Number of demographics in the person demographics array. **/
int fNumberPersonDemographics;

/** Array of synthetic person records, one for each member of the
 * household.
* The number of valid entries in this array is given by
* the fNumberPersons field.
*/
SyntheticPersonData *fPersons;

} SyntheticHHData;
```

2. ACTIVITIES

2.1 Interface Functions

The activity subsystem has C structures and utility functions that are used to read and write activity data from a TRANSIMS activity file. These functions assume that all of the activities for a household are grouped sequentially in the TRANSIMS activity file.

2.1.1 **moreActivities**

Signature `int moreActivities (FILE* const fp)`

Description Boolean function used to control iteration through the activity file.

Argument `fp` – the `FILE*` pointer for the activity file, which must be open for reading.

Return Value 1 if not at end of activity file.
0 if EOF has been reached.

2.1.2 **getNextActivity**

Signature `const ActivityData* getNextActivity (FILE* const)`

Description Reads an activity from the activity file. Parses and converts the string values from the file and stores them in a static `ActivityData` structure. Allocates storage for the `fOtherParticipantsList` and `fLocations` arrays based on data in the file.

Argument `fp` – the `FILE*` pointer to the activity, which must be open for reading.

Return Value The address of an unmodifiable `ActivityData` structure containing the activity data from the file.
NULL on error.

2.1.3 **getNextHousehold**

Signature `const ActivityData* getNextHousehold (FILE* const fp,
int* arraySize)`

Description Reads the activities for a household from the activity file.
Constructs an `ActivityData` structure for each activity in the
household. Parses the activities and stores them in an array of
`ActivityData` structures.

Argument `fp` – the `FILE*` pointer to the activity file, which must be open for
reading.

Return Value An array of unmodifiable `ActivityData` structures that contains the
activity data for the household. Returns `NULL` on error. The number of
activities for the household is returned in the `arraySize` argument.

2.1.4 **writeActivity**

Signature `int writeActivity (FILE* const fp,
const ActivityData * data)`

Description Writes the given `ActivityData` into a line of the given activity file.

Argument `fp` – the `FILE*` pointer to the activity file, which must be open for
writing.
`data` – the address of an `ActivityData` structure containing the data
to be written.

Return Value 1 on success.
0 on error.

2.1.5 **writeHousehold**

Signature `int writeHousehold (FILE* fp,
ActivityData* data, int arraySize)`

Description Writes the activities for a household into the given file.

Argument `fp` – the `FILE*` pointer to the activity file, which must be open for writing.

`data` – the address of an `ActivityData` array containing the household

activity data to be written.

`arraySize` – the number of activities in the data array.

Return Value 1 on success.
0 on error.

2.1.6 **moreTripTableEntries**

Signature `int moreTripTableEntries (FILE* const)`

Description Boolean function used to control iteration through the trip table file.

Argument `fp` – the `FILE*` pointer to the trip table file, which must be open for reading.

Return Value 1 if not at end of trip table file.
0 if EOF has been reached.

2.1.7 **getTripTableDimensions**

Signature `void getTripTableDimensions (FILE* fp const, int *x,
int *y)`

Description Returns the x and y dimensions of the trip table.

Argument `fp` – the `FILE*` pointer to the trip table file, which must be open for reading.

`x` – the address of an integer that will contain the x dimension of the trip table.

`y` – the address of an integer that will contain the y dimension of the trip table.

Return Value The dimensions of the trip table are returned in the x and y arguments.

2.1.8 `getNextTripTableEntry`

Signature `const TTripTableEntry* getNextTripTableEntry (FILE* const)`

Description Reads the next trip table entry from the trip table file. Stores the information in a static `TTripTableEntry` structure and returns the address of this structure.

Argument `fp` – the `FILE*` pointer to the trip table file, which must be open for reading.

Return Value The address of a static `TTripTableEntry` structure that contains the data for the entry.
NULL on error.

2.1.9 `moreTimeTableEntries`

Signature `int moreTimeTableEntries (FILE* const)`

Description Boolean function used to control iteration through the time table file.

Argument `fp` – the `FILE*` pointer to the time table file, which must be open for reading.

Return Value 1 if not at end of time table file.
0 if EOF has been reached.

2.1.10 `getNextTimeTableEntry`

Signature `const getpNextTimeTableEntry (FILE* const)`

Description Reads the next time table entry from the time table file. Stores the information in a static `TTimeTableEntry` structure and returns the address of this structure.

Argument `fp` – the `FILE*` pointer to the time table file, which must be open for reading.

Return Value The address of a static `TTimeTableEntry` structure that contains the data for the entry.
NULL on error.

2.1.11 **CreateActivityIndex**

Signature void **CreateActivityIndex** (const char* actFileName)

Description Creates a household and traveler index for a TRANSIMS activity file. The household index has the household id as the primary key and produces the file <actFileName>.hh.idx. The traveler index has the traveler id as the primary key and produces the file <actFileName>trv.idx.

Argument actFileName – the name of the TRANSIMS activity file.

2.1.12 **moreSurveyActivities**

Signature int **moreSurveyActivities** (FILE* fp const)

Description Boolean function used to control iteration through a survey activities file.

Argument fp – FILE* pointer for the survey activity, which must be open for reading.

Return Value 1 if not at end of survey activity file
0 if EOF has been reached.

2.1.13 **readSurveyActivityHeader**

Signature int **readSurveyActivityHeader** (FILE* fp const)

Description Reads the header line in the survey activity file.

Argument fp – the FILE* pointer for the survey activity, which must be open for reading.

Return Value 1 on success.
0 on error.

2.1.14 `getSurveyActivity`

Signature `const TSurveyActivityEntry* getSurveyActivity
(FILE* fp const)`

Description Reads a survey activity from the survey activity file and stores the data in a static `TSurveyActivityEntry` structure.

Argument `fp` – `FILE*` pointer to the survey activity file, which must be open for reading.

Return Value The address of an unmodifiable `TSurveyActivityEntry` structure containing the survey activity data from the file.
NULL on error.

2.1.15 `getSurveyWeightFromFile`

Signature `const TSurveyWeightEntry* getSurveyWeightFromFile
(FILE* const)`

Description Reads a survey weight entry from the file and stores the data in a static `TSurveyWeightEntry` structure.

Argument `fp` – the `FILE*` pointer to the survey weight file, which must be open for reading.

Return Value The address of an unmodifiable `TSurveyWeightEntry` structure containing the survey activity data from the file.
NULL on error.

2.1.16 `getSurveyWeightFromData`

Signature `const TSurveyWeightEntry* getSurveyWeightFromData
(char* const)`

Description Get a survey weight entry from the data pointer and store the data in a static `TSurveyWeightEntry` structure.

Argument `fp` – the `char*` pointer to the data character buffer.

Return Value The address of an unmodifiable `TSurveyWeightEntry` structure containing the survey activity data from the file.
NULL on error.

2.1.17 moreTravelTimes

Signature int **moreTravelTimes** (FILE* const)

Description Boolean function used to control iteration through a travel times file.

Argument fp – the FILE* pointer for the travel times file, which must be open for reading.

Return Value 1 if not at end of survey activity file
0 if EOF has been reached.

2.1.18 getTravelTimeEntryFromFile

Signature const TTravelTimeEntry* **getTravelTimeEntryFromFile** (FILE* const)

Description Reads a travel time entry from the file and stores the data in a static TTravelTimeEntry structure.

Argument fp – the FILE* pointer to the travel time file, which must be open for reading.

Return Value The address of an unmodifiable TTravelTimeEntry structure containing the travel time data from the file.
NULL on error.

2.1.19 getTravelTimeEntryFromData

Signature const TTravelTimeEntry* **getTravelTimeEntryFromData** (char* const)

Description Get a travel time entry from the data pointer and store the data in a static TTravelTimeEntry structure.

Argument fp – the char* pointer to the data character buffer.

Return Value The address of an unmodifiable TTravelTimeEntry structure containing the travel time data.
NULL on error.

2.1.20 `writeTravelTimeEntry`

Signature `int writeTravelTimeEntry (const TTravelTimeEntry* const)`

Description Writes a travel time entry to a file.

Argument `entry` – to a `TTravelTimeEntry` structure containing the data to be written to the file.
`fp` – the `FILE*` pointer to the file where the entry will be written; must be open for writing.

Return Value 1 on success.
0 on error.

2.1.21 `moreTreeEntries`

Signature `int moreTreeEntries (FILE* const)`

Description Boolean function used to control iteration through a decision tree file.

Argument `fp` – the `FILE*` pointer for the decision tree file, which must be open for reading.

Return Value 1 if not at the end of decision tree file.
0 if EOF has been reached.

2.1.22 `getTreeEntryFromFile`

Signature `const TTreeEntry* getTreeEntryFromFile (FILE* const)`

Description Reads a decision tree entry from the file and stores the data in a static `TTreeEntry` structure.

Argument `fp` – the `FILE*` pointer to the decision tree file, which must be open for reading.

Return Value The address of an unmodifiable `TTreeEntry` structure containing the decision tree data from the file.
NULL on error.

2.1.23 **getTreeEntryFromData**

Signature const TTreeEntry **getTreeEntryFromData** (char* const)

Description Get a decision tree entry from the data pointer and store the data in a static TTreeEntry structure.

Argument fp – the char* pointer to the data character buffer.

Return Value The address of an unmodifiable TTreeEntry structure containing the decision tree data.
NULL on error.

2.1.24 **moreZoneEntries**

Signature int **moreZoneEntries** (FILE* const)

Description Boolean function used to control iteration through a zone information file.

Argument fp – the FILE* pointer for the zone information file, which must be open for reading.

Return Value 1 if not at end of zone information file.
0 if EOF has been reached.

2.1.25 **getZoneHeaderFromFile**

Signature const TZoneHeader* **getZoneHeaderFromFile** (FILE* const)

Description Reads the zone header from the file and stores the data in a static TZoneHeader structure.

Argument fp – the FILE* pointer to the zone information file, which must be open for reading.

Return Value The address of an unmodifiable TZoneHeader structure containing the header data from the file.
NULL on error.

2.1.26 `getZoneEntryFromFile`

Signature `const TZoneEntry* getZoneEntryFromFile
FILE* const, int)`

Description Reads a zone entry from the file and stores the data in a static `TZoneEntry` structure.

Argument `fp` – the `FILE*` pointer to the zone information file, which must be open for reading.

Return Value The address of an unmodifiable `TZoneEntry` structure containing the zone data from the file.
NULL on error.

2.1.27 `getZoneEntryFromData`

Signature `const TZoneEntry* getZoneEntryFromData
(char* const, int)`

Description Get a zone entry from the data pointer and store the data in a static `TZoneEntry` structure.

Argument `fp` – the `char*` pointer to the data character buffer.

Return Value The address of an unmodifiable `TZoneEntry` structure containing the zone data.
NULL on error.

2.1.28 `moreModeWeightEntries`

Signature `int moreModeWeightEntries (FILE* const)`

Description Boolean function used to control iteration through a mode weight file.

Argument `fp` – the `FILE*` pointer for the mode weight file, which must be open for reading.

Return Value 1 if not at end of mode weight file.
0 if EOF has been reached.

2.1.29 `getModeWeightEntryFromData`

Signature `const TModeWeightEntry* getModeWeightEntryFromData
(char* const)`

Description Get a mode coefficient entry from the data pointer and store the data in a static `TModeWeightEntry` structure.

Argument `fp` – the `char*` pointer to the data character buffer.

Return Value The address of an unmodifiable `TModeWeightEntry` structure containing the zone data.
NULL on error.

2.1.30 `getModeWeightEntryFromFile`

Signature `const TModeWeightEntry* getModeWeightEntryFromFile
(FILE* const)`

Description Reads a mode weight entry from the file and stores the data in a static `TModeWeightEntry` structure.

Argument `fp` – the `FILE*` pointer to the mode weight file, which must be open for reading.

Return Value The address of an unmodifiable `TModeWeightEntry` structure containing the mode weight data from the file.
NULL on error.

2.1.31 `moreModeEntries`

Signature `int moreModeEntries (FILE* const)`

Description Boolean function used to control iteration through a TRANSIMS mode file.

Argument `fp` – the `FILE*` pointer for the mode file, which must be open for reading.

Return Value 1 if not at end of mode.
0 if EOF has been reached.

2.1.32 **getModeEntryFromFile**

Signature const TModeEntry* **getModeEntryFromFile** (FILE* const)

Description Reads a mode entry from the file and stores the data in a static TModeEntry structure.

Argument fp – the FILE* pointer to the mode file, which must be open for reading.

Return Value The address of an unmodifiable TModeEntry structure containing the mode data from the file.
NULL on error.

2.1.33 **CreateFeedbackIndex**

Signature void **CreateFeedbackIndex** (const char* FileName)

Description Creates an index to the feedback command file with household ID as the primary key and traveler ID as the secondary key.

Argument FileName – name of the feedback command file to be indexed.

Return Value None.

2.1.34 **CreateTravelTimesIndex**

Signature void **CreateTravelTimesIndex** (const char* FileName)

Description Creates an index to the travel times file with zone 1 as the primary index and zone 2 as the secondary index.

Argument FileName – name of the travel times file to be indexed.

Return Value None.

2.2 Data Structures

2.2.1 ActivityTimeSpec

This structure is used for activity time specifications.

```
typedef struct act_time_spec_s
{
    /** The lower bound of the time interval. */
    REAL fLowerBound;

    /** The upper bound of the time interval. */
    REAL fUpperBound;

    /** The A parameter for the beta distribution. */
    REAL fAParameter;

    /** The B parameter for the beta distribution. */
    REAL fBParameter;

} ActivityTimeSpec;
```

Each activity has a start time, end time, and duration range. The preferred time for each of these is given in terms of the two parameters of a beta distribution, $f(t)=C(t-L)^{a-1}(U-t)^{b-1}$, where C is a constant, L is the lower bound of the time, U is the upper bound and a and b are the parameters that specify the distribution. The mean of the distribution is $a/(a+b)$; $a=1$ and $b=1$ give a uniform distribution between L and U . Larger values for a and b result in a more peaked distribution. If the a and/or b parameter is equal to -1.0, an average of the lower and upper bound will be used.

The reference time is taken as 0.00 (midnight of the first day). All times are decimal numbers that denote the number of hours from 0.00. Note that each time should be given to a minimum of two decimal places to capture minutes and four decimal places if seconds are necessary.

2.2.2 ActivityData

This structure is used to store the data for a single activity as defined by one line in the activity file.

```
typedef struct actdata_s
{
    /** The household ID. */
    INT32 fHouseholdId;
```

```
/** The person ID. */
INT32 fPersonId;

/** The activity ID — must be unique within the household. */
INT32 fActivityId;

/** The activity type. An integer value representing
 * the activity type such as home, work, school, shopping,
 * other, wait at transit stop, . . .
*/
INT32 fType;

/** The priority ranking of the activity in the range 0 - 9,
 * where 0 is the lowest priority and 9 means the activity
 * must be done.
*/
INT32 fPriority;

/** The integer value defining transportation mode used to arrive
 * at the activity.
*/
INT32 fModePreference;

/** The ID of the vehicle to be used when the mode preference is
 * private auto, either as a driver or passenger. Set to -1 for
 * all other mode preferences.
*/
INT32 fVehicleId;

/** The number of locations where the activity can take place.
 * This field is used to provide information about the
 * fActivityGroupIndex and fPossibleLocationsList fields.
 * A value of 1 or greater indicates that the
 * fPossibleLocationsList contains a list of locations for the
 * activity. A value of -1 indicates that the
 * fActivityGroupIndex field contains an index number into a
 * group of activities.
*/
INT32 fPossibleLocations;

/** The number of other people that will participate in the
 * activity and use the same transportation. Value is 0 if the
 * person is traveling alone to the activity. If the value is >
 * 0, a list of the IDs of the other participants is entered in
 * the fOtherParticipantsList array.
*/
INT32 fOtherParticipants;
```

```
/** The number of the activity for this individual. Every
 * activity for an individual has a number. Groups of activities
 * that must be done together have the same number.
 */
INT32 fActivityGroupNumber;

/** An array of personIDs for other participants in the activity
 * that will use the same transportation. There are no valid
 * entries in this array if the value of fOtherParticipants
 * is 0.
*/
INT32 *fOtherParticipantsList;

/** The index into a group of activities (integer).
 * Used only when the value of fPossibleLocations is -1.
*/
INT32 fActivityGroupIndex;

/** An array of possible locations (integer IDs) where
 * the activity will occur. Used when the value of
 * fPossibleLocations is 1 or greater.
*/
INT32 *fLocations;

/** The preferred start time for the activity. The
 * ActivityTimeSpec structure contains the specification
 * parameters for a beta distribution of the preferred time.
*/
ActivityTimeSpec fStart;

/** The preferred end time for the activity. The
 * ActivityTimeSpec structure contains the specification
 * parameters for a beta distribution of the preferred time.
*/
ActivityTimeSpec fEnd;

/** The preferred duration for the activity. The ActivityTimeSpec
 * structure contains the specification parameters for a beta
 * distribution of the preferred time.
*/
ActivityTimeSpec fDuration;

} ActivityData;
```

2.2.3 TTripTableEntry

This structure is used to store a two-dimensional table containing the number of trips between zones.

```
typedef struct triptableentry_s
{
    /** The number of the X zone. */
    int fZoneX;

    /** The number of the Y zone. */
    int fZoneY;

    /** The number of trips between fZoneX and fZoneY */
    int fNumberTrips;
} TTripTableEntry;
```

2.2.4 TTimeTableEntry

This structure is used to store entries from a trip time probability table that contains a range of times over a 24-hour period. Each range has an associated trip probability.

```
typedef struct timetableentry_s
{
    /** The lower bound of the time range. */
    float fRangeL;

    /** The upper bound of the time range. */
    float fRangeU;

    /** The probability associated with the time range. */
    float fProb;
} TTimeTableEntry;
```

2.2.5 TSurveyActivityEntry

This structure stores the data for a survey activity as defined by one line in the survey activity file.

```
/** A survey activity entry */

typedef struct TSurveyActivityEntry_s
{
    /** The survey household number. */
    INT32 fHHNumber;
```

```
/** The person number (unique within the household) ***/
INT32 fPersonNumber;

/** The activity number for each person, 0 - n.
 * 0 = initial at home activity.
*/
INT32 fActivityNumber;

/** The activity type, 0 = at home, 1 = work, 22 = *
 * serve_passengers. Others may vary.
*/
INT32 fType;

/** 1 if activity is at home location, 0 if out of home. */
INT32 fAtHome;

/** Value = 1 if person was already at the location,
 * value = 2 if not.
*/
INT32 fWereYouThere;

/** The mode for arriving at an activity. -1 if mode from the
 * survey was missing.
*/
INT32 fMode;

/** Value = 1 if person was driver, 2 if person was a passenger,
 * -1 otherwise.
*/
INT32 fDriver;

/** The activity start time in minutes after midnight
 * (0 - 2400).
*/
INT32 fStartTime;

/** The activity end time in minutes after midnight
 * (0 - 2400).
*/
INT32 fEndTime;

/** Number of persons in vehicle */
INT32 fNumberInVehicle;

/** X coordinate of survey activity */
REAL fXCoord;
```

```
/** Y coordinate of survey activity */
REAL fYCoord;

} TSurveyActivityEntry;
```

2.2.6 TTravelTimeEntry

This structure stores data for one zone-to-zone travel time entry as contained in one line of the travel times file.

```
/** An activity generator travel time entry.
 * Travel time values are from zone to zone
 * by mode and time of day.
 */

typedef struct TTravelTimeEntry_s
{

/** The zone numbers */
INT32 fZone1;
INT32 fZone2;

/** The mode */
INT32 fMode;

/** The start time */
REAL fStartTime;

/**The end time */
REAL fEndTime;

/** The travel time */
REAL fValue;

/** The time the entry was updated. */
INT32 fLastUpdate;

} TTravelTimeEntry;
```

2.2.7 TFeedbackEntry

This structure is used to store the data from an Activity Generator feedback command.

```
/** An Activity Generator feedback file entry.
 * An entry contains the household id,
 * the activity id, the command, and
 * optional arguments to the command.
 * If the command is change time of the activity,
 * the new start, end, start alpha and beta,
 * and end alpha and beta are specified as
 * arguments.
 */
typedef struct TFeedbackEntry_s
{
    /** The household ID **/
    INT32 fHouseholdId;

    /** The activity ID **/
    INT32 fActivityId;

    /** The feedback command **/
    char fCommand[MAX_FEEDBACK_COMMAND_LENGTH];

    /** The number of valid arguments in the fArguments array. **/
    int fValidArgs;

    /** The optional arguments to the command. **/
    REAL fArguments[MAX_NUMBER_FEEDBACK_ARGUMENTS];
} TFeedbackEntry;
```

2.2.8 TTTreeEntry

This structure is used to store the data for a node in the Activity Generator regression tree.

```
/** An entry defining a node in the Activity Generator decision
 * tree. Each node contains a demographic, a split value for the
 * demographic, and a node number that specified it's
 * relationship in the tree.
 */
typedef struct TTTreeEntry_s
{
    /** The demographic number. **/
    INT32 fDemographic;
```

```

/** The split value for the demographic. */
REAL fSplitValue;

/** The node number. */
INT32 fNodeNumber;

} TTreeEntry;

```

2.2.9 TZoneHeader

This structure is used to store the header information from the Activity Generator zone information file.

```

/** Stores the column headings from the header line
 * in the zone information data.
 * The number of column headings is variable.
**/

typedef struct TZoneHeader_s
{
    /** The number of columns in the line. */
    int fNumberHeaders;

    /** The array of character strings containing the column
     * headings for the attractor values in the zone.
     * Each column header can have up to MAX_HEADER_LENGTH
     * characters. This is a dynamically allocated
     * two-dimensional array fAttractorHeaders[()][]
    **/
    char **fAttractorHeaders;
} TZoneHeader;

```

2.2.10 TZoneEntry

This structure is used to store data for a zone entry from the Activity Generator zone information file.

```

typedef struct TZoneEntry_s
{
    /** The zone number. */
    INT32 fNumber;

    /** The easting geocoordinate for the zone. */
    REAL fEasting;

    /** The northing geocoordinate for the zone. */
    REAL fNorthing;
}

```

```

/** The number of attractors by activity type for the zone.
 * The work attractor is required, so the number must
 * be 1 or greater. These types MUST correspond to
 * the activity type definitions in the Activity Generator.
*/
INT32 fNumberAttractors;

/** The array of floating-point values for the attractors by
 * activity type in the zone. The first value in the
 * array is for the work attractor, which is required.
*/
REAL *fAttractors;

} TZoneEntry;

```

2.2.11 TModeWeightEntry

This structure is used to store a mode weight entry from the Activity Generator mode coefficient file.

```

/** A mode coefficient entry for the NISS activity generator.
 * Each mode can be assigned a relative weight.
*/
typedef struct TModeWeightEntry_s
{

/** The coefficient for the mode. */
REAL fWeight;

/** The activity type */
INT32 fActivityType;

/** The mode */
INT32 fMode;

} TModeWeightEntry;

```

2.2.12 TModeEntry

This structure is used to store an entry from a TRANSIMS mode map file.

```
/** A mode string and number entry.  
 *  Each entry has a mode string, e.g. "wcw"  
 *  and an integer value associated with the mode.  
 */  
  
typedef struct TModeEntry_s  
{  
    /** The mode string **/  
    char fModeString[MAX_MODE_STRING_LENGTH];  
  
    /** The number associated with the mode string. **/  
    int fMode;  
  
} TModeEntry;
```

3. VEHICLE

3.1 Interface Functions

The vehicle subsystem has C structures and utility functions that are used to read and write data from a TRANSIMS vehicle file.

The function **getNextVehicle ()** reads vehicle data from a vehicle file in ASCII format. The function stores the information in an unmodifiable data structure (**VehicleData**), and returns a pointer to the structure. Since the **VehicleData** structure cannot be modified by the calling program, the data should be copied if it needs to be changed.

The function **writeVehicle ()** takes a **VehicleData** structure as an argument containing the information to be written. The **getNextVehicle ()** function combined with the **moreVehicles ()** function provides a mechanism for iterating through the vehicle file reading the vehicle data.

3.1.1 moreVehicles

Signature int **moreVehicles** (FILE* const fp)

Description Boolean function used to control iteration through the vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be open for reading.

Return Value 1 if not at end of vehicle file.
 0 if EOF has been reached.

3.1.2 **getNextVehicle**

Signature const VehicleData* **getNextVehicle** (FILE* const fp)

Description Reads a line of vehicle data from the vehicle file. Parses and converts the string values from the file and stores them in the static VehicleData structure fVehicle.

Argument fp – the FILE* pointer for the vehicle file, which must be open for reading.

Return Value The address of a static VehicleData structure containing the vehicle data read from the file.
NULL on error.

3.1.3 **writeVehicle**

Signature int **writeVehicle** (FILE* const fp,
const VehicleData* data)

Description Writes the given VehicleData into a line of the given vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be open for reading.
data – the address of a VehicleData structure containing the data to be written.

Return Value 1 on success.
0 on error.

3.1.4 **VehDataReadHeader**

Signature int **VehDataReadHeader** (FILE* fp,
TVehDataHeader* header)

Description Reads the header line from the vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be opened for reading.
header – TVehDataHeader* to a header structure.

Return Value 1 if header read successfully.
0 if error occurs.

3.1.5 VehDataWriteHeader

Signature int **VehDataWriteHeader** (FILE* fp,
TVEhDataHeader* header)

Description Writes a header line to the vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be opened for writing.
header – TVEhDataHeader* to a header structure.

Return Value 1 if header written successfully.
0 if error occurs.

3.1.6 VehDataWriteDefaultHeader

Signature int **VehDataWriteDefaultHeader** (FILE* fp)

Description Writes a default header line to the vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be opened for writing.

Return Value 1 if header written successfully.
0 if error occurs.

3.1.7 VehDataSkipHeader

Signature int **VehDataSkipHeader** (FILE* fp)

Description Skip a header from a vehicle file.

Argument fp – the FILE* pointer for the vehicle file, which must be opened for reading.

Return Value 1 if header skipped successfully.
0 if error occurs.

3.2 Data Structures

3.2.1 TVehDataHeader

This structure is used to store a vehicle file header.

```
typedef struct
{
    /** The field names. */
    INT8 fFields[512]

} TVehDataHeader;
```

3.2.2 VehicleData

This structure is used to store the data for a single vehicle as defined by one line in the vehicle file.

```
typedef struct vehdata_s
{
    /** The household ID. */
    INT32 fHouseholdId;

    /** The vehicle ID. */
    INT32 fVehicleId;

    /** The ID starting location of the vehicle. -1 is used if
     * the starting location is unknown or to indicate that the
     * Route Planner should choose the starting location.
    */
    INT32 fStartingLocation;

    /** The TRANSIMS Network vehicle type.
     * Must be one of the following values:
     *   1 = Auto
     *   2 = Truck
     *   4 = Taxi
     *   5 = Bus
     *   6 = Trolley
     *   7 = StreetCar
     *   8 = LightRail
     *   9 = RapidRail
     *  10 = RegionalRail
     *  -1 = Unknown
    */
    INT32 fVehicleType;
```

```

/** The user-defined emissions vehicle subtype. */
INT32 fEmissionsSubtype;

/** The number of values in the fIdentifiers array. */
INT32 fNumberIdentifiers;

/** The optional array of user-defined integer values.
 * The number of entries in the array is variable
 * but must be the same for every line of the file.
 * If no user-defined values are present in the file,
 * fIdentifiers will be NULL.
*/
INT32 *fIdentifiers;

} VehicleData;

```

3.2.3 TVehDataHeader

This structure is used to store the data for a vehicle location file.

```

typedef struct
{

/* The field names. */
INT8 fFields[512];

} TVehDataHeader;

/** Reads a header from a vehicle location file.
 * Returns nonzero if the header was
 * successfully read, or zero if not.
*/
extern int VehDataReadHeader (FILE* file, TVehDataHeader*
header);

/** Writes a header to a vehicle location file.
 * Returns nonzero if the header was
 * successfully written, or zero if not.
*/
extern int VehDataWriteHeader (FILE* file,
const TVehDataHeader* header);

/** Writes a default header to a vehicle location file.
 * Returns nonzero if the header was successfully written,
 * or zero if not.
*/
extern int VehDataWriteDefaultHeader (FILE* file);

```

```
/** Skips a header from a vehicle location file.  
 * Returns nonzero if the header was successfully skipped,  
 * or zero if not. **/  
extern int VehDataSkipHeader (FILE* file);  
}
```

3.3 Files

Table 1: Vehicle library files.

Type	File Name	Description
Binary Files	<i>libTIO.a</i>	The TRANSIMS Interfaces library.
Source Files	<i>vehio.c</i>	The source file for vehicle file functions.
	<i>vehio.h</i>	The header file for vehicle file functions.

4. VEHICLE PROTOTYPES

This section describes the C structures and utility functions that are used to read and write TRANSIMS vehicle prototype files. Vehicle prototype files are used to describe parameters for vehicle types and subtypes such as length and capacity of the vehicle, as well as maximum speed and acceleration.

4.1 Interface Functions

4.1.1 VehReadHeader

Signature `int VehReadHeader (FILE* file, TVehHeader* header)`

Description Reads a header from a vehicle prototype file.

Argument `file` – the pointer to the `FILE` stream object.
`header` – the pointer to a vehicle prototype header structure.

Return Value Nonzero if the header was successfully read, or zero if not.

4.1.2 VehWriteHeader

Signature `int VehWriteHeader (FILE* file,
const TVehHeader* header)`

Description Writes a header from a vehicle prototype file.

Argument `file` – the pointer to the `FILE` stream object.
`header` – pointer to a vehicle prototype header structure.

Return Value Nonzero if the header was successfully written, or zero if not.

4.1.3 VehWriteDefaultHeader

Signature `int VehWriteDefaultHeader (FILE* file)`

Description Writes a default header from a vehicle prototype file.

Argument `file` – the pointer to the `FILE` stream object.

Return Value Nonzero if the header was successfully written, or zero if not.

4.1.4 VehSkipHeader

Signature int **VehSkipHeader** (FILE* file)

Description Skips a header from a vehicle prototype file.

Argument file – the pointer to the FILE stream object.

Return Value Nonzero if the header was successfully skipped, or zero if not.

4.1.5 VehReadPrototype

Signature int **VehReadPrototype** (FILE* file,
TVehPrototypeData* record)

Description Reads a record from a vehicle prototype file.

Argument file – the pointer to the FILE stream object.
record – the pointer to a vehicle prototype record structure.

Return Value Nonzero if the record was successfully read, or zero if not.

4.1.6 VehWritePrototype

Signature int **VehWritePrototype** (FILE* file,
const TVehPrototypeData* record)

Description Writes a record to a vehicle prototype file.

Argument file – the pointer to the FILE stream object.
record – the pointer to a vehicle prototype record structure.

Return Value Nonzero if the record was successfully written, or zero if not.

4.2 Data Structures

4.2.1 TVehHeader

This structure is used to store the vehicle prototype as defined by one line in the vehicle file.

```
typedef struct
{
    /** The field names. */
    INT8 fFields[512]

} TVehHeader;
```

4.2.2 TVehPrototypeData

This structure is used for vehicle prototype file records.

```
typedef struct
{
    /** The vehicle type. */
    INT32 fVehicleType;

    /** The vehicle subtype, used for emissions. */
    INT32 fEmissionsSubtype;

    /** The maximum vehicle speed (meters/second). */
    REAL fMaximumVelocity;

    /** The maximum vehicle acceleration (meters/second/seconds). */
    REAL fMaximumAcceleration;

    /** The vehicle length (meters). */
    REAL fLength;

    /** The vehicle capacity (driver + number of possible
     * passengers).
     */
    INT32 fCapacity;

} TVehPrototypeData;
```

4.3 Files

Table 2: Vehicle Prototype library files.

Type	File Name	Description
Binary Files	<i>libTIO.a</i>	The TRANSIMS Interfaces library.
Source Files	<i>vehprotoio.c</i>	The source file for vehicle prototype file functions.
	<i>vehprotoio.h</i>	The header file for vehicle prototype file functions.

5. PLAN

The Route Planner and Traffic Microsimulator have C structures and utility functions that are used to read and write TRANSIMS plan files.

5.1 Interface Functions

The function **getNextLegRecord()** reads a single leg of a traveler's plan from a plan file. The function stores the information in a static data structure (**LegData**) and returns a pointer to a structure data. The **LegData** structure cannot be modified by the calling program. The data should be copied if it needs to be changed. The function **writeLeg()** is used to create a TRANSIMS plan file.

5.1.1 **moreLegs**

Signature int **moreLegs** (FILE* const fp)

Description The Boolean function used to control iteration through the plan file.

Argument fp – the FILE* pointer for the plan file, which must be open for reading.

Return Value 1 if not at end of plan file.
0 if EOF has been reached.

5.1.2 **getNextLeg**

Signature const LegData* **getNextLeg** (FILE* const fp)

Description Reads a single leg of a traveler's plan from the plan file. Parses and converts the non-mode-dependent values from the file and stores them in the static **LegData** structure.

Argument fp – the FILE* pointer for the plan file, which must be open for reading.

Return Value The address of the static **LegData** structure containing the data read from the file.
NULL on error.

5.1.3 **writeLeg**

Signature int **writeLeg** (FILE* const fp, const LegData* leg)

Description Writes the given LegData into the given plan file.

Argument fp – the FILE* pointer to the plan file, which must be open for reading.

Return Value 1 on success.
0 on error.

5.1.4 **readLegRecordFromString**

Signature int **readLegRecordFromString** (char* buf)

Description Reads and parses the data for a LegData record from a data string. The data string need not be null terminated.

Argument buf – the data character string.

Return Value 1 always.

5.1.5 **readLegRecord**

Signature int **readLegRecord** (FILE* const fp)

Description Reads a single leg of a traveler's plan from the plan file and stores it in a static character buffer. Note that it does not parse the record, nor does it update the contents of the static LegData structure. Selective parsing of records provides a fast means of retrieving only a few pieces of data from each leg of a plan file.

Argument fp – the FILE* pointer for the plan file, which must be open for reading.

Return Value 1 on success.
0 on error.

5.1.6 **writeLegRecord**

Signature int **writeLegRecord** (FILE* const fp)

Description Writes the current string stored in the static character buffer into the given plan file.

Argument fp – the FILE* pointer to the plan file, which must be open for writing.

Return Value Number of characters written.

5.1.7 **parseBufferedLegRecord**

Signature int **parseBufferedLegRecord** (void)

Description Parses all of the non-mode-dependent fields of the traveler's leg data stored in the static character buffer. Fills in the fields of the static LegData structure.

Return Value 1 always.
0 on failure.

5.1.8 **getCurrentLeg**

Signature const LegData* **getCurrentLeg** (void)

Description Retrieve the information currently stored in the static LegData structure.

Return Value The address of the static LegData structure maintained by **parseBufferedLegRecord**, **readLegRecordFromString**, and **readLegRecord**.

5.1.9 **getLegTravelerId**

Signature int **getLegTravelerId**(void)

Description Parses the traveler ID field from the static character buffer and stores the result in the traveler ID field of the static LegData structure.

Return Value Traveler ID from the current leg.

5.1.10 `getLegDepartTime`

Signature `int getLegDepartTime (void)`

Description Parses the estimated departure time field from the static character buffer and stores the result in the estimated departure time field of the static LegData structure.

Return Value Estimated departure time from the current leg.

5.1.11 `getLegStartAccessoryId`

Signature `int getLegStartAccessoryId (void)`

Description Parses the starting accessory ID field from the static character buffer and stores the result in the starting accessory ID field of the static LegData structure.

Return Value Starting accessory ID from the current leg.

5.1.12 `getLegStartAccessoryType`

Signature `int getLegStartAccessoryType (void)`

Description Parses the starting accessory type field from the static character buffer and stores the result in the starting accessory type field of the static LegData structure.

Return Value Starting accessory type from the current leg.

5.1.13 `getLegTripId`

Signature `int getLegTripId ()`

Description Parses the trip ID field from the static character buffer and stores the result in the trip ID field of the static LegData structure.

Return Value Trip ID from the current leg.

5.1.14 **getLegLegId**

Signature int **getLegLegId** (void)

Description Parses the leg ID from the static character buffer and stores the result in the leg ID field of the static LegData structure.

Return Value Leg ID from the current leg

5.1.15 **getLegMode**

Signature int **getLegMode** (void)

Description Parses the mode field from the static character buffer and stores the result in the mode field of the static LegData structure.

Return Value Mode from the current leg.

5.1.16 **DefragmentPlanFiles**

Signature void **DefragmentPlanFiles**(char* filename,
BTree* index)

Description Creates one new plan file from an index that specifies multiple plan files.

Argument filename – the pointer to a character string containing the name of the new plan file.
index – the pointer to the existing index.

Return Value None.

5.1.17 ReverseIndex

Signature void **ReverseIndex** (BTree* new, BTree* old)

Description Create a new index from an existing index by interchanging the primary and secondary keys.

Argument new – the pointer to the new index, should have been prepared with BTree_Create prior to running **ReverseIndex**.
old – the pointer to the existing index.

Return Value None.

5.2 Data Structures

5.2.1 LegData

This structure is used to hold one leg of a traveler's plan.

```
typedef struct plandata_s
{
    /** The fixed part of the data structure. */
    /** The TRANSIMS traveler ID */
    UINT32 fTravId;

    /** A user defined field. */
    INT32 fUser;

    /** The trip sequence number. */
    INT32 fTrip;

    /** The leg sequence number. */
    INT32 fLeg;

    /** The (estimated) departure time in seconds past midnight. */
    INT32 fActivationTime;

    /** The ID of the accessory at which this leg starts. */
    INT32 fStartAcc;

    /** The type of the accessory at which this leg starts. */
    INT32 fStartAccType;

    /** The ID of the accessory at which this leg ends. */
    INT32 fEndAcc;

    /** The type of the accessory at which this leg ends. */
    INT32 fEndAccType;

    /** The (estimated) duration of this leg in seconds. */
    INT32 fDuration;

    /** The (estimated) ending time of this leg in seconds past
     * midnight.
    */
    INT32 fStopTime;
```

```
/** A flag telling the Traffic Microsimulator whether to use the
 * maximum or minimum of fStopTime and (fDuration + simulation
 * time at arrival) for determining the ending time of a leg
 * using a non-simulated mode.
*/
INT32 fMaxTime;

/** The dollar cost of this leg. */
INT32 fCost;

/** The cost of this leg under a user-defined generalized cost
 * function. */
INT32 fGCF;

/** Is the traveler driving a vehicle on this leg? */
INT32 fDriverFlag;

/** The travel mode for this leg. */
INT32 fMode;

/** The variable (mode dependent) part of the data structure. */
char * fData;

} LegData;
```

6. ITERATION DATABASE

6.1 Interface Functions

In any function that takes a string representing a record as an argument, an empty field is represented by two consecutive commas (i.e., “,,”). In any function that takes an array of strings representing a record as an argument, a blank field can be represented by either an empty string or a NULL pointer to a string. The last pointer in the array should be NULL.

The *String* functions return a null-terminated string that is a copy of the record/field requested. The contents of the string are modifiable, and the string needs to be freed after use.

If a particular field is empty, it is assumed that the value for that field has not changed since the last iteration.

The *Data* functions return a pointer into the mmapped file in which the record/field resides. Changing data through this pointer will change the actual iteration file where the data resides. This pointer should not be freed.

6.1.1 ITDB_Create

Signature `ITDB* ITDB_Create (char* base_filename, char* fields)`

Description Creates a new iteration database.

Argument `base_filename` – the filename to create files with; `filename.idx` for the index and `filename.#.it` for each iteration, where # is the iteration number.
`fields` – the field names as a comma-separated string.

Return Value A pointer to a new iteration database on iteration 0.

6.1.2 **ITDB_CreateV**

Signature `ITDB* ITDB_CreateV (char* base_filename,
char* fields[], int key)`

Description Creates a new iteration database with the given filename.

Argument `base_filename` – the filename to create files with; *filename.idx* for the index and *filename.#.it* for each iteration, where # is the iteration number.
`fields` – the field names as an array of strings.
`key` – the value of the key for which to return records.

Return Value A pointer to a new iteration database on iteration 0.

6.1.3 **ITDB_Open**

Signature `ITDB* ITDB_Open (char* base_filename)`

Description Opens an existing ITDB.

Argument `base_filename` – the filename of the ITDB.

Return Value A pointer to an existing iteration database on the same iteration it had when closed.

6.1.4 **ITDB_Close**

Signature `void ITDB_Close (ITDB* db)`

Description Closes an ITDB and free all resources. Upon return, `db` is no longer a valid pointer.

Argument `db` – the database to close.

Return Value None.

6.1.5 ITDB_CurrentIteration

Signature `int ITDB_CurrentIteration (ITDB* db)`

Description Returns the current iteration number.

Argument `db` – the itdb on which to operate.

Return Value Current iteration number.

6.1.6 ITDB_NewIteration

Signature `int ITDB_NewIteration (ITDB* db, char* comment)`

Description Starts on a new iteration.

Argument `db` – the itdb on which to operate.

`comment` – a comment to be stored as the first line of the new iteration file.

Return Value New iteration number.

6.1.7 ITDB_Add

Signature `void ITDB_Add (ITDB* db, int key, char* data)`

Description Adds data to `key` for the current iteration. If data exists for the key given, the new data is added to the index following the old data.

Argument `db` – the itdb on which to operate.

`key` – the value of the primary key.

`data` – a comma-separated string of field values.

Return Value None.

6.1.8 ITDB_AddV

Signature void **ITDB_AddV** (ITDB*, int key, char* data[])

Description Adds data to key for the current iteration. If data already exists for the key given, the new data is added to the index following the old data.

Argument db – the itdb on which to operate.
key – the value of the primary key.
data – an array of field values.

Return Value None.

6.1.9 ITDB_GetCurrentString

Signature char* **ITDB_GetCurrentString** (ITDB* db, int key)

Description Gets data for key from the current iteration.

Argument db – the itdb in which to operate.
key – the value of key for which to retrieve information.

Return Value Null-terminated copy of the data. The caller is responsible for deleting this string.

6.1.10 GetCurrentData

Signature char* **ITDB_GetCurrentData** (ITDB* db, int key)

Description Gets data for key from the current iteration.

Argument db – the itdb on which to operate.
key – the value of the key for which to retrieve data.

Return Value A pointer into the mmapped field. Changes to the string will change the actual file. This pointer should not be freed.

6.1.11 **ITDB_GetString**

Signature `char* ITDB_GetString (ITDB* db, int it, int key)`

Description Gets data for `key` from the given iteration.

Argument `db` – the `itdb` on which to operate.

`it` – the iteration from which to retrieve data.

`key` – the value of the key for which to retrieve information.

Return Value Null-terminated copy of the data. The caller is responsible for deleting this string.

6.1.12 **ITDB_GetData**

Signature `char* ITDB_GetData ITDB* db, int it, int key)`

Description Gets data for `key` from the given iteration.

Argument `db` – the `itdb` on which to operate.

`it` – the iteration from which to retrieve data.

`key` – the value of the key for which to retrieve information.

Return Value A pointer into the mmapped file. Changes to the string will change the actual file. This pointer should not be freed.

6.1.13 **ITDB_GetTotalString**

Signature `char* ITDB_GetTotalString (ITDB* db, int key)`

Description Returns the latest data over all iterations for `key`. Searches back through the iterations for the last non-blank entry for each field.

Argument `db` – the `itdb` on which to operate.

`key` – the value of the key for which to retrieve information.

Return Value Null-terminated copy of the data. The caller is responsible for deleting this string.

6.1.14 ITDB_GetCurrentField

Signature `char* ITDB_GetCurrentField (ITDB* db, int key, int field)`

Description Returns the specific field for the current iteration for `key`.

Argument `db` – the itdb on which to operate.

`key` – the value of the `key` for which to retrieve information.

`field` – the field to retrieve.

Return Value String containing specified field.

6.1.15 ITDB_GetField

Signature `char* ITDB_GetField (ITDB* db, int key, int field, int it)`

Description Returns the specified field for the specified iteration for `key`.

Argument `db` – the itdb on which to operate.

`key` – the value of the `key` for which to retrieve information.

`field` – the field to retrieve.

`it` – the iteration from which to retrieve information

Return Value String containing specified field.

6.1.16 ITDB_GetFirstField

Signature `char* ITDB_GetFirstField (ITDB* db, int key, int field, int it)`

Description Returns the specified field for the earliest iteration that has data.

Argument `db` – the itdb on which to operate.

`key` – the value of the `key` for which to retrieve information.

`field` – the field to retrieve.

`it` – the iteration from which to retrieve information.

Return Value String containing specified field.

6.1.17 ITDB_GetLastField

Signature `char* ITDB_GetLastField (ITDB* db, int key, int field, int it)`

Description Returns the specified field for the latest iteration that has data.

Argument `db` – the itdb on which to operate.

`key` – the value of the key for which to retrieve information.

`field` – the field to retrieve.

`it` – the iteration from which to retrieve information.

Return Value String containing specified field.

6.1.18 ITDB_FieldNameToNumber

Signature `int ITDB_FieldNameToNumber (ITDB* db, char* name)`

Description Converts between field name and field number.

Argument `db` – the itdb on which to operate.

`name` – the name to look up.

Return Value Number of the given field, or -1 if it was not found.

6.1.19 ITDB_FieldNumberToName

Signature `char* ITDB_FieldNumberToName (ITDB* db, int num)`

Description Converts between field number and field name.

Argument `db` – the itdb on which to operate.

`num` – the number to look up.

Return Value String containing the field name, or NULL if it was not found.

6.1.20 **ITDB_ItCreate**

Signature `ITDB_It* ITDB_ItCreate (ITDB* db, int iteration)`

Description Creates an iterator for the records of the given iteration.

Argument `db` – the database over which to iterate.
`iteration` – the number of the iteration over which to iterate.
If `iteration` is `-1`, then do all iterations.

Return Value An iterator set to the first record of the proper iteration.

6.1.21 **ITDB_ItCreateRecord**

Signature `ITDB_It* ITDB_ItCreateRecord (ITDB* db, int key)`

Description Creates an iterator for all iterations of the given record.

Argument `db` – the database over which to iterate.
`key` – the value of the key for which to return records.

Return Value An iterator set to the first record of the proper iteration.

6.1.22 **ITDB_ItDestroy**

Signature `void ITDB_ItDestroy (ITDB_It* it)`

Description Destroys an iterator and frees all resources.

Argument `it` – the iterator to destroy.

Return Value None.

6.1.23 **ITDB_ItReset**

Signature `void ITDB_ItReset (ITDB_It* it)`

Description Resets the iterator to beginning.

Argument `it` – the iteration on which to operate.

Return Value None.

6.1.24 **ITDB_ItAdvance**

Signature void **ITDB_ItAdvance** (ITDB_It* *it*)

Description Advances to the next record.

Argument *it* – the iteration on which to operate.

Return Value None.

6.1.25 **ITDB_ItMoreData**

Signature int **ITDB_ItMoreData** (ITDB_It* *it*)

Description Is there more data?

Argument *it* – the iteration on which to operate.

Return Value 0 if there is no more data.
non-zero if there is more data.

6.1.26 **ITDB_ItGetString**

Signature char* **ITDB_ItGetString** (ITDB_It* *it*)

Description Returns the current record.

Argument *it* – the iteration on which to operate.

Return Value A null-terminated string containing a copy of the record. The caller is responsible for freeing this data.

6.1.27 **ITDB_ItGetData**

Signature char* **ITDB_ItGetData** (ITDB_It* *it*)

Description Returns the current record.

Argument *it* – the iteration on which to operate.

Return Value A pointer into the mmapped file. Changes to the string will change the actual file. This pointer should not be freed.

6.1.28 **ITDB_StringToArray**

Signature `char** ITDB_StringToArray (char* str)`

Description Converts a single string containing multiple fields to an array of strings containing single records.

Argument `str` – a string containing comma-separated fields.

Return Value An array of strings, one field per string. The last element of the array is `NULL`. The caller is responsible for freeing the returned pointer.

6.1.29 **ITDB_ArrayToString**

Signature `char* ITDB_ArrayToString (char** array)`

Description Convert an array of fields to a single string.

Argument `array` – an array of strings containing fields. The last element of the array must be set to `NULL`.

Return Value A single string containing the comma-separated fields.

6.2 Data Structures

6.2.1 ITDB

This structure contains all of the information about an iteration database.

```
typedef struct itdb_s
{
    /** The current iteration number. */
    int iteration;

    /** Used to construct the itdb filename. */
    char* base_filename;

    /** The name of the current iteration file; base.#.it. */
    char* idx_filename;

    /** The file descriptor for the current iteration file. */
    int it_fd;

    /** The array of labels for the fields of the database. */
    char* field_labels;

    /** The number of fields. */
    int num_fields;

    /** The end of the current iteration file. */
    size_t it_pos;

    /** The index of all iteration files. */
    BTREE* index;
} ITDB;
```

6.2.2 ITDB_It

This structure is an iterator into an iteration database.

```
typedef struct itdbit_s
{
    /** The index for this iterator. */
    BTTree* index;

    /** The index iterator. */
    BTTreeIt* index_it;

    /** The iteration to iterate through. -1 means all iterations.
     */
    int iteration;

    /** Iterate through one record only. -1 means all records. */
    int key;
} ITDB_It;
```

7. SIMULATION OUTPUT

The simulation output subsystem has C structures and utility functions that are used to read and write TRANSIMS simulation output files.

7.1 Interface Functions

7.1.1 OutReadHeader

Signature `int OutReadHeader (FILE* file, TOutHeader* header)`

Description Reads a header from an output table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.2 OutWriteHeader

Signature `int OutWriteHeader (FILE* file,
const TOutHeader* header)`

Description Writes a header to an output table.

Argument `file` – pointer to a FILE stream object.
`header` – pointer to an output table header structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.3 OutSkipHeader

Signature `int OutSkipHeader (FILE* file)`

Description Skips a header from an output table.

Argument `file` – the pointer to a FILE stream object.

Return Value Nonzero if the header was successfully skipped, or zero if not.

7.1.4 OutHeaderHasField

Signature int **OutHeaderHasField** (const TOutHeader* header,
const char* field)

Description Determines whether an output table header contains a specified field.

Argument header – the pointer to an output table header structure.
field – the pointer to a character string.

Return Value Nonzero if the header contains the specified field, or zero if not.

7.1.5 OutReadNodeSpecification

Signature int **OutReadNodeSpecification** (FILE* file,
TOutNodeSpecificationRecord* record)

Description Reads a record from a node specification table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an output node specification record structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.6 OutWriteNodeSpecification

Signature int **OutWriteNodeSpecification** (FILE* file, const
TOutNodeSpecificationRecord* record)

Description Writes a record to a node specification table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an output node specification record structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.7 OutReadLinkSpecification

Signature int **OutReadLinkSpecification** (FILE* file,
TOutLinkSpecificationRecord* record)

Description Reads a record from a link specification table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an output link specification structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.8 OutWriteLinkSpecification

Signature int **OutWriteLinkSpecification** (FILE* const
TOutLinkSpecificationRecord* record)

Description Writes a record to a link specification table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an output link specification structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.9 OutReadTravelerEventHeader

Signature int **OutReadTravelerEventHeader** (FILE* file,
TOutHeader* header, TOutTravelerEventRecord* record)

Description Reads a header from a traveler event table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a traveler event structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.10 OutWriteTravelerEventHeader

Signature `int OutWriteTravelerEventHeader (FILE* file, const TOutHeader * header, TOutTravelerEventRecord * record)`

Description Writes a header to a traveler event table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a traveler event structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.11 OutReadTravelerEvent

Signature `int OutReadTravelerEvent (FILE* file, TOutTravelerEventRecord* record)`

Description Reads a record from a traveler event table.

Argument `file` – the pointer to a FILE stream object.
`record` – the pointer to a traveler event structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.12 OutReadTravelerEventFromString

Signature `int OutReadTravelerEventFromString (const char* buf, TOutTravelerEventRecord* record)`

Description Reads a record from a character buffer (which may not be null terminated).

Argument `buf` – the pointer to a character string.
`record` – the pointer to a traveler event structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.13 OutWriteTravelerEvent

Signature `int OutWriteTravelerEvent (FILE* file,
const TOutTravelerEventRecord* record)`

Description Writes a record to a traveler event table.

Argument `file` – the pointer to a FILE stream object.
`record` – the pointer to a traveler event structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.14 OutReadVehicleEvolutionHeader

Signature `int OutReadVehicleEvolutionHeader (FILE* file,
TOutHeader* header,
TOutVehicleEvolutionRecord* record)`

Description Reads a header from a vehicle evolution table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a vehicle evolution structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.15 OutWriteVehicleEvolutionHeader

Signature `int OutWriteVehicleEvolutionHeader (FILE* file,
const TOutHeader* header,
TOutVehicleEvolutionRecord* record)`

Description Writes a header to a vehicle evolution table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a vehicle evolution structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.16 OutReadVehicleEvolution

Signature int **OutReadVehicleEvolution** (FILE* file,
TOutVehicleEvolutionRecord* record)

Description Reads a record from a vehicle evolution table.

Argument file – pointer to a FILE stream object.
record – pointer to a vehicle evolution structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.17 OutWriteVehicleEvolution

Signature int **OutWriteVehicleEvolution** (FILE* file,
const TOutVehicleEvolutionRecord* record)

Description Writes a record to a vehicle evolution table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a vehicle evolution structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.18 OutReadIntersectionEvolutionHeader

Signature int **OutReadIntersectionEvolutionHeader** (FILE* file,
TOutHeader* header,
TOutIntersectionEvolutionRecord* record)

Description Reads a header from an intersection evolution table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to an intersection evolution structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.19 OutWriteIntersectionEvolutionHeader

Signature int **OutWriteIntersectionEvolutionHeader** (FILE* file,
const TOutHeader* header,
TOutIntersectionEvolutionRecord* record)

Description Writes a header to an intersection evolution table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to an intersection evolution structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.20 OutReadIntersectionEvolution

Signature int **OutReadIntersectionEvolution** (FILE* file,
TOutIntersectionEvolutionRecord* record)

Description Reads a record from an intersection evolution table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an intersection evolution structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.21 OutWriteIntersectionEvolution

Signature int **OutWriteIntersectionEvolution** (FILE* file,
const TOutIntersectionEvolutionRecord* record)

Description Writes a record to an intersection evolution table.

Argument file – the pointer to a FILE stream object.
record – the pointer to an intersection evolution structure

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.22 OutReadTrafficControlEvolutionHeader

Signature `int OutReadTrafficControlEvolutionHeader (FILE* file,
 TOutHeader* header,
 TOutTrafficControlEvolutionRecord* record)`

Description Reads a header from a traffic control evolution table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a traffic control evolution structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.23 OutWriteTrafficControlEvolutionHeader

Signature `int OutWriteTrafficControlEvolutionHeader (FILE* file,
 const TOutHeader header,
 TOutTrafficControlEvolutionRecord record)`

Description Writes a header to a traffic control evolution table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a traffic control evolution structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.24 OutReadTrafficControlEvolution

Signature `int OutReadTrafficControlEvolution (FILE* file,
 TOutTrafficControlEvolutionRecord record)`

Description Reads a record from a traffic control evolution table.

Argument `file` – the pointer to a FILE stream object.
`record` – the pointer to a traffic control evolution structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.25 OutWriteTrafficControlEvolution

Signature int **OutWriteTrafficControlEvolution** (FILE* file,
const TOutTrafficControlEvolutionRecord record)

Description Writes a record to a traffic control evolution table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a traffic control evolution structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.26 OutReadLinkTimeSummaryHeader

Signature int **OutReadLinkTimeSummaryHeader** (FILE* file,
TOutHeader * header, TOutLinkTimeSummaryRecord*
record)

Description Reads a header from a link time summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link time summary structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.27 OutWriteLinkTimeSummaryHeader

Signature int **OutWriteLinkTimeSummaryHeader** (FILE* file,
const TOutHeader* header,
TOutLinkTimeSummaryRecord* record)

Description Writes a header to a link time summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link time summary structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.28 OutReadLinkTimeSummary

Signature int **OutReadLinkTimeSummary** (FILE* file,
TOutLinkTimeSummaryRecord* record)

Description Reads a record from a link time summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link time summary structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.29 OutWriteLinkTimeSummary

Signature int **OutWriteLinkTimeSummary** (FILE* file,
const TOutLinkTimeSummaryRecord* record)

Description Writes a record to a link time summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link time summary structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.30 OutReadLinkSpaceSummaryHeader

Signature int **OutReadLinkSpaceSummaryHeader** (FILE* file,
TOutHeader* header,
TOutLinkSpaceSummaryRecord* record)

Description Reads a header from a link space summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link space summary structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.31 OutWriteLinkSpaceSummaryHeader

Signature int **OutWriteLinkSpaceSummaryHeader** (FILE* file,
const TOutHeader* header,
TOutLinkSpaceSummaryRecord* record)

Description Writes a header to a link space summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link space summary structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.32 OutReadLinkSpaceSummary

Signature int **OutReadLinkSpaceSummary** (FILE* file,
TOutLinkSpaceSummaryRecord* record)

Description Reads a record from a link space summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link space summary structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.33 OutWriteLinkSpaceSummary

Signature int **OutWriteLinkSpaceSummary** (FILE* file,
const TOutLinkSpaceSummaryRecord* record)

Description Writes a record to a link space summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link space summary structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.34 OutReadLinkVelocitySummaryHeader

Signature `int OutReadLinkVelocitySummaryHeader (FILE* file,
TOutHeader* header,
TOutLinkVelocitySummaryRecord* record)`

Description Reads a header from a link velocity summary table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table structure defined.
`TOutLinkVelocitySummaryRecord` – pointer to a link velocity summary structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.35 OutWriteLinkVelocitySummaryHeader

Signature `int OutWriteLinkVelocitySummaryHeader (FILE* file,
const TOutHeader* header,
TOutLinkVelocitySummaryRecord* record)`

Description Writes a header to a link velocity summary table.

Argument `file` – the pointer to a FILE stream object.
`header` – the pointer to an output table header structure.
`record` – the pointer to a link velocity summary structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.36 OutReadLinkVelocitySummary

Signature `int OutReadLinkVelocitySummary (FILE* file,
TOutLinkVelocitySummaryRecord* record)`

Description Reads a record to a link velocity summary table.

Argument `file` – the pointer to a FILE stream object.
`record` – the pointer to a link velocity summary structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.37 OutWriteLinkVelocitySummary

Signature int **OutWriteLinkVelocitySummary** (FILE* file,
const TOutLinkVelocitySummaryRecord* record)

Description Writes a record to a link velocity summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link velocity summary structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.38 OutReadLinkEnergySummaryHeader

Signature int **OutReadLinkEnergySummaryHeader** (FILE* file,
TOutHeader* header,
TOutLinkEnergySummaryRecord* record)

Description Reads a header to a link energy summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link energy summary structure.

Return Value Nonzero if the header was successfully read, or zero if not.

7.1.39 OutWriteLinkEnergySummaryHeader

Signature int **OutWriteLinkEnergySummaryHeader** (FILE* file,
const TOutHeader* header,
TOutLinkEnergySummaryRecord* record)

Description Writes a header to a link energy summary table.

Argument file – the pointer to a FILE stream object.
header – the pointer to an output table header structure.
record – the pointer to a link energy summary structure.

Return Value Nonzero if the header was successfully written, or zero if not.

7.1.40 OutReadLinkEnergySummary

Signature int **OutReadLinkEnergySummary** (FILE* file,
TOutLinkEnergySummaryRecord* record)

Description Reads a record to a link energy summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link energy summary structure.

Return Value Nonzero if the record was successfully read, or zero if not.

7.1.41 OutWriteLinkEnergySummary

Signature int **OutWriteLinkEnergySummary** (FILE* file,
const TOutLinkEnergySummaryRecord* record)

Description Writes a record to a link energy summary table.

Argument file – the pointer to a FILE stream object.
record – the pointer to a link energy summary structure.

Return Value Nonzero if the record was successfully written, or zero if not.

7.1.42 CreateEventFileIndex

Signature void **CreateEventFileIndex** (const char* filename)

Description Creates two indexes for a traveler event file. The first index (with extension *.trv.idx*) is sorted by traveler ID as the primary key and trip ID as the secondary key. The second index (with extension *.loc.idx*) is sorted by location ID as the primary key and traveler ID as the secondary key.

Argument filename – pointer to a character string containing the name of a traveler event file.

Return Value None.

7.2 Data Structures

7.2.1 TOutHeader

This structure is used for the output table header.

```
typedef struct
{
    /** The field names. */
    INT8 fFields[512];

} TOutHeader;
```

7.2.2 TOutNodeSpecificationRecord

This structure is used for output node specification table records.

```
typedef struct
{
    /** The NODE field. */
    INT32 fNode;

} TOutNodeSpecificationRecord;
```

7.2.3 TOutLinkSpecificationRecord

This structure is used for output link specification table records.

```
typedef struct
{
    /** The LINK field. */
    INT32 fLink;

} TOutLinkSpecificationRecord;
```

7.2.4 TOutTravelerEventRecord

This structure is used for traveler event records.

```
typedef structure
{
    /** The TIME field. */
    REAL64 fTime;
```

```
/** The TRAVELER field. */
INT32 fTraveler;

/** The TRIP field. */
INT32 fTrip;

/** The LEG field. */
INT32 fLeg;

/** The VEHICLE field. */
INT32 fVehicle;

/** The VEHTYPE field. */
INT32 fVehtype;

/** The VSUBTYPE field. */
INT32 fVsubtype;

/** The ROUTE field. */
INT32 fRoute;

/** The STOPS field. */
INT32 fStops;

/** The YIELDS field. */
INT32 fYields;

/** The SIGNALS field. */
INT32 fSignals;

/** The TURN field. */
INT32 fTurn;

/** The STOPPED field. */
REAL64 fStopped;

/** the ACCELS field. */
REAL64 fAccels;

/** The TIMESUM field. */
REAL64 fTimesum;

/** The DISTANCESUM field. */
REAL64 fDistancesum;

/** The USER field. */
INT32 fUser;

/** The ANOMALY field. */
INT32 fAnomaly;
```

```

/** The STATUS field. */
INT32 fStatus;

/** The LINK field. */
INT32 fLink;

/** The NODE field. */
INT32 fNode;

/** The LOCATION field. */
INT32 fLocation;

/** Private: The i/o formats. */
INT8 fFormat[2] [93];

/** Private: The pointers to the data. */
INT32 fOffsets[22];

} TOutTravelerEventRecord;

```

7.2.5 TOutVehicleEvolutionRecord

This structure is used for vehicle evolution records.

```

typedef struct
{

/** The TIME field. */
REAL64 fTime;

/** The DRIVER field. */
INT32 fDriver;

/** The VEHICLE field. */
INT32 fVehicle;

/** The VEHTYPE field. */
INT32 fVehtype;

/** The LINK field. */
INT32 fLink;

/** The NODE field. */
INT32 fNode.;

/** The LANE field. */
INT32 fLane;

/** The DISTANCE field. */
REAL64 fDistance;

```

```

/** The VELOCITY field. */
REAL64 fVelocity;

/** The ACCELER field. */
REAL64 fAcceler;

/** The PASSENGERS field. */
INT32 fPassengers;

/** The EASTING field. */
REAL64 fEasting;

/** The NORTHING field. */
REAL64 fNorthing;

/** The ELEVATION field. */
REAL64 fElevation;

/** The AZIMUTH field. */
REAL64 fAzimuth;

/** The USER field. */
INT32 fUser;

/** Private: The i/o formats. */
INT8 fFormat[2] [72];

/** Private: The pointers to the data. */
INT32 fOffsets[16];

} TOutVehicleEvolutionRecord;

```

7.2.6 TOutIntersectionEvolutionRecord

This structure is used for intersection evolution records.

```

typedef struct
{
    /** The TIME field. */
    REAL64 fTime;

    /** The VEHICLE field. */
    INT32 fVehicle;

    /** The NODE field. */
    INT32 fNode;

    /** The LINK field. */
    INT32 fLink;
}

```

```
/** The LANE field. */
INT32 fLane;

/** The QINDEX field. */
INT32 fQindex;

/** Private: The i/o formats. */
INT8 fFormat[2] [25];

/** Private: The pointer to the data. */
INT32 fOffsets [6];

} TOutIntersectionEvolutionRecord;
```

7.2.7 TOutTrafficControlEvolutionRecord

This structure is used for traffic control evolution records.

```
typedef struct
{

/** The TIME field. */
REAL64 fTime;

/** The NODE field. */
INT32 fNode;

/** The LINK field. */
INT32 fLink;

/** The LANE field. */
INT32 fLane;

/** The SIGNAL field. */
INT32 fSignal;

/** Private: The i/o formats. */
INT8 fFormat [2] [21];

/** Private: The pointers to the data. */
INT32 fOffsets[5];

} TOutTrafficControlEvolutionRecord;
```

7.2.8 TOutLinkTimeSummaryRecord

This structure is used for link time summary records.

```
typedef struct
{
    /** The TIME field. */
    REAL64 fTime;

    /** The LINK field. */
    INT32 fLink;

    /** The NODE field. */
    INT32 fNode;

    /** The LANE field. */
    INT32 fLane;

    /** The TURN field. */
    INT32 fTurn;

    /** The COUNT field. */
    INT32 fCount;

    /** The SUM field. */
    REAL64 fSum;

    /** The SUMSQUARES field. */
    REAL64 fSumsquares;

    /** The VCOUNT field. */
    INT32 fVCount;

    /** The VSUM field. */
    REAL64 fVSum;

    /** The VSUMSQUARES field. */
    REAL64 fVSumsquares;

    /** Private: The i/o formats. */
    INT8 fFormat[2] [49];

    /** Private: The pointers to the data. */
    INT32 fOffsets[11];
} TOutLinkTimeSummaryRecord;
```

7.2.9 TOutLinkSpaceSummaryRecord

This structure is used for link space summary records.

```
typedef struct
{
    /** The TIME field. */
    REAL64 fTime;

    /** The LINK field. */
    INT32 fLink;

    /** The NODE field. */
    INT32 fNode;

    /** The LANE field. */
    INT32 fLane;

    /** The DISTANCE field. */
    REAL64 fDistance;

    /** The COUNT field. */
    INT32 fCount;

    /** The SUM field. */
    REAL64 fSum;

    /** The SUMSQUARES field. */
    REAL64 fSumsquares;

    /** Private: The i/o formats. */
    INT8 fFormat[2] [36];

    /** Private: The pointers to the data. */
    INT32 fOffsets[8];
} TOutLinkSpaceSummaryRecord;
```

7.2.10 TOutLinkVelocitySummaryRecord

This structure is used for link velocity summary records.

```
/** The maximum allowed number of bins in a histogram. */
#define HISTOGRAM_MAX_BINS 100

/** The structure for link velocity summary records. */
typedef struct
{
```

```

/** The TIME field. */
REAL64 fTime;

/** The LINK field. */
INT32 fLink;

/** The NODE field. */
INT32 fNode.

/** The DISTANCE field. */
READ64 fDistance;

/** The COUNT fields. */
INT32 fCount [HISTOGRAM_MAX_BINS];

/** The number of bins in the histogram. */
INT32 fNumberBins;

/** Private: The i/o formats. */
INT8 fFormat[2] [18 + 4 * HISTOGRAM_MAX_BINS];

/** Private: The pointers to the data. */
INT32 fOffsets[4 + HISTOGRAM_MAX_BINS];

} TOutLinkVelocitySummaryRecord;

```

7.2.11 TOutLinkEnergySummaryRecord

This structure is used for link energy summary records.

```

/** The maximum allowed number of bins in a histogram. */
#define HISTOGRAM_MAX_BINS_100

/** The structure for link energy summary records. */
typedef struct
{

/** The TIME field. */
REAL64 fTime;

/** The LINK field. */
INT32 fLink;

/** The NODE field. */
INT32 fNode;

/** The ENERGY fields. */
INT32 fEnergy[HISTOGRAM_MAX_BINS];

```

```
/** The number of bins in the histogram. **/
INT32 fNumberBins;

/** Private: The i/o formats. **/
INT8 fFormat[2] [13 + 3 * HISTOGRAM_MAX_BINS];

/** Private: The pointers to the data. **/
INT32 fOffsets[3 + HISTOGRAM_MAX_BINS];

} TOutLinkEnergySummaryRecord;
```

8. TRANSIT

The transit subsystem has C structures and utility functions used to read and write data from a TRANSIMS transit route file, a TRANSIMS transit schedule file, or a TRANSIMS transit zone file.

8.1 Interface Functions

The function `getNextTransitRouteData ()` reads transit route data from a transit route file in ASCII format. The function stores the information in an unmodifiable data structure (`TransitRouteData`) and returns a pointer to the structure. Because the calling program cannot modify the `TransitRouteData` structure, the data should be copied if it needs to be changed.

The function `writeTransitRouteData ()` takes a `TransitRouteData` structure as an argument containing the information to be written.

All of these functions work similarly:

- `getNextTransitScheduleData ()`
- `writeTransitScheduleData ()`
- `getNextZoneData()`
- `writeTransitZoneData ()`

The `getNextTransitRouteData ()`, `getNextTransitScheduleData ()`, or `getNextTransitZoneData ()` function, when combined with the `moreTransit ()` function, provide a mechanism for iterating through the appropriate transit file.

8.1.1 moreTransitData

Signature `int moreTransitData (FILE* const)`

Description The Boolean function used to control iteration through the transit file.

Argument `fp` – the `FILE*` pointer for the transit file, which must be open for reading.

Return Value 1 if not at end of transit data file.
 0 if EOF has been reached.

8.1.2 `getNextTransitRouteData`

Signature `const TransitRouteData* getNextTransitRouteData
(FILE* const fp)`

Description Reads transit route data from the transit route file.

Argument `fp` – the `FILE*` pointer to the transit route file, which must be open for reading.

Return Value The address (containing the transit route read from the file) of a `TransitRouteData` structure.
NULL on error.

8.1.3 `writeTransitRouteData`

Signature `int writeTransitRouteData
(FILE* const fp, TransitRouteData* data)`

Description Writes the `TransitRouteData` into a line of the given transit route file.

Argument `fp` – `FILE*` to the transit route file, which must be open for reading.
`data` – the address of a `TransitRouteData` structure containing the data to be written.

Return Value 1 on success.
0 on error.

8.1.4 `getNextTransitScheduleData`

Signature `const TransitScheduleData* getNextTransitScheduleData
(FILE* const fp)`

Description Reads transit schedule data from the transit schedule file.

Argument `fp` – the `FILE*` pointer to the transit schedule file, which must be open for reading.

Return Value The address (containing the transit schedule read from the file) of a `TransitScheduleData` structure.
NULL on error.

8.1.5 writeTransitScheduleData

Signature int **writeTransitScheduleData**
 (FILE* const fp, TransitScheduleData* data)

Description Writes the given TransitScheduleData into a line of the given transit schedule file.

Argument fp – the FILE * pointer to the transit schedule file, which must be open for writing.
 data – the address of a TransitScheduleData structure containing the data to be written.

Return Value 1 on success.
 0 on error.

8.1.6 getNextTransitZoneData

Signature const TransitZoneData* **getNextTransitZoneData**
 (FILE* const fp)

Description Reads transit zone data from the transit zone file.

Argument fp – the FILE* pointer to the transit zone file, which must be open for reading.

Return Value The address of a TransitZoneData structure containing the transit zone read from the file.
 NULL on error.

8.1.7 writeTransitZoneData

Signature int **writeTransitZoneData** (FILE* const fp,
 TransitZoneData* data)

Description Writes the given TransitZoneData into a line of the given transit route file.

Argument fp – the FILE* pointer to the transit zone file, which must be open for writing.
 data – the address of a TransitZoneData structure containing the data to be written.

Return Value 1 on success.
 0 on error.

8.2 Data Structures

8.2.1 TransitStopData

This structure is used for transit stop data as specified in the transit route file.

```
typedef struct transitstopdata_s
{
    /** The stop ID. */
    INT32 fStopId;

    /** /The link ID. */
    INT32 fLinkId;

    /** The node ID. */
    INT32 fNodeId;

    /** The transit zone (0 if none) */
    INT32 fTransitZone;

} TransitStopData;
```

8.2.2 TransitRouteData

This structure is used for transit route data as specified in the transit route file.

```
typedef struct transitroutedata_s
{
    /** The route Id. */
    INT32 fRouteId;

    /** The number of stops. */
    INT32 fNumStops;

    /** The type of transit for this route. */
    INT8 fTransitType[16];

    /** An array of info about stops for this route */
    TransitStopData *fStops;

} TransitRouteData;
```

8.2.3 TransitScheduleData

This structure is used for transit schedule data as specified in the transit schedule file.

```
typedef struct transitscheduledata s
{
    /** The stop Id. */
    INT32 fStopId;

    /** The route Id. */
    INT32 fRouteId;

    /** The arrival time. */
    INT32 fArrivalTime;

} TransitScheduleData;
```

8.2.4 TransitZoneData

This structure is used for transit zone data as specified in the transit zone file.

```
typedef struct transitzonedata s
{
    /** The source zone. */
    INT32 fFromZone;

    /** The destination zone. */
    INT32 fToZone;

    /** The cost of travel from FromZone to ToZone on TransitType,
     * in cents.
    */
    INT32 fCost;

    /** The type of transit for this route. */
    INT8 fTransitType[16];

} TransitZoneData;
```

9. NETWORK

9.1 Interface Functions

The following section deals with the network subsystem, which has C structures and utility functions for reading and writing network data files.

9.1.1 NetReadHeader

Signature `int NetReadHeader (FILE* file, TNetHeader* header)`

Description Reads a header from a network table.

Argument `file` – the `FILE*` pointer for the network data table.
`header` – the pointer to the `TNetHeader` structure into which the header is read.

Return Value Nonzero if the header was successfully read, or zero if not.

9.1.2 NetWriteHeader

Signature `int NetWriteHeader (FILE* file,
const TNetHeader* header)`

Description Writes a header from a network table.

Argument `file` – the `FILE*` pointer for the network data table.
`header` – the pointer to `TNetHeader` structure from which the header is written.

Return Value Nonzero if the header was successfully written, or zero if not.

9.1.3 NetSkipHeader

Signature `int NetSkipHeader (FILE* file)`

Description Skip a header from a network table.

Argument `file` – the `FILE*` pointer for the network data table.

Return Value Nonzero if the header was successfully skipped, or zero if not.

9.1.4 NetReadActivityLocationHeader

Signature int **NetReadActivityLocationHeader** (FILE* file, TNetHeader* header, TNetActivityLocationRecord* record)

Description Reads a header from an activity location table.

Argument file – the FILE* pointer for the network data table.
header – the pointer to the TNetHeader structure into which the header is read.
record – the pointer to the TNetActivityLocationRecord structure which is initialized based on the header contents.

Return Value Nonzero if the header was successfully read, or zero if not.

9.1.5 NetReadNode

Signature int **NetReadNode** (FILE* file, TNetNodeRecord* record)

Description Reads a record from a node table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetNodeRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.6 NetWriteNode

Signature int **NetWriteNode** (FILE* file, const TNetNodeRecord* record)

Description Writes a record to a node table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetNodeRecord structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.7 NetReadLink

Signature int **NetReadLink** (FILE* file, TNetLinkRecord* record)

Description Reads a record from a link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLinkRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.8 NetWriteLink

Signature int **NetWriteLink** (FILE* file,
const TNetLinkRecord* record)

Description Writes a record to a link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLinkRecord structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.9 NetReadSpeed

Signature int **NetReadSpeed** (FILE* file, TNetSpeedRecord* record)

Description Reads a record from a speed table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetSpeedRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.10 NetWriteSpeed

Signature int **NetWriteSpeed** (FILE* file,
const TNetSpeedRecord* record)

Description Writes a record to a speed table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetSpeedRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.11 NetReadPocket

Signature int **NetReadPocket** (FILE* file,
TNetPocketRecord* record)

Description Reads a record from a pocket lane table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetPocketRecord structure into which
the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.12 NetWritePocket

Signature int **NetWritePocket** (FILE* file,
const TNetPocketRecord* record)

Description Writes a record to a pocket lane table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetPocketRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.13 NetReadLaneUse

Signature int **NetReadLaneUse** (FILE* file,
TNetLaneUseRecord* record)

Description Reads a record from a lane use table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLaneUseRecord structure into
which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.14 NetWriteLaneUse

Signature int **NetWriteLaneUse** (FILE* file,
const TNetLaneUseRecord* record)

Description Writes a record to a lane use table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLaneUseRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.15 NetReadParking

Signature int **NetReadParking** (FILE* file,
TNetParkingRecord* record)

Description Reads a record from a parking table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetParkingRecord structure into
which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.16 NetWriteParking

Signature int **NetWriteParking** (FILE* file,
const TNetParkingRecord* record)

Description Writes a record to a parking table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetParkingRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.17 NetReadBarrier

Signature int **NetReadBarrier** (FILE* file,
TNetBarrierRecord* record)

Description Reads a record from a barrier table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetBarrierRecord structure into which
the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.18 NetWriteBarrier

Signature int **NetWriteBarrier** (FILE* file,
const TNetBarrierRecord* record)

Description Writes a record to a barrier table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetBarrierRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.19 NetReadTransitStop

Signature int **NetReadTransitStop** (FILE* file,
TNetTransitStopRecord* record)

Description Reads a record from a transit stop table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTransitStopRecord structure into
which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.20 NetWriteTransitStop

Signature int **NetWriteTransitStop** (FILE* file,
const TNetTransitStopRecord* record)

Description Writes a record to a transit stop table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTransitStopRecord structure
from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.21 NetReadLaneConnectivity

Signature int **NetReadLaneConnectivity** (FILE* file,
TNetLaneConnectivityRecord* record)

Description Reads a record from a lane connectivity table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLaneConnectivityRecord
structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.22 NetWriteLaneConnectivity

Signature int **NetWriteLaneConnectivity** (FILE* file,
const TNetLaneConnectivityRecord* record)

Description Writes a record to a lane connectivity table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetLaneConnectivityRecord structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.23 NetReadTurnProhibition

Signature int **NetReadTurnProhibition** (FILE* file,
TNetTurnProhibitionRecord* record)

Description Reads a record from a turn prohibition table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTurnProhibitionRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.24 NetWriteTurnProhibition

Signature int **NetWriteTurnProhibition** (FILE* file,
const TNetTurnProhibitionRecord* record)

Description Writes a record to a turn prohibition table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTurnProhibitionRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.25 NetReadUnsignalizedNode

Signature int **NetReadUnsignalizedNode** (FILE* file,
TNetUnsignalizedNodeRecord* record)

Description Reads a record from an unsignalized node table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetUnsignalizedNodeRecord
structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.26 NetWriteUnsignalizedNode

Signature int **NetWriteUnsignalizedNode**(FILE* file,
const TNetUnsignalizedNodeRecord* record)

Description Writes a record to an unsignalized node table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetUnsignalizedNodeRecord
structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.27 NetReadSignalizedNode

Signature int **NetReadSignalizedNode** (FILE* file,
TNetSignalizedNodeRecord* record)

Description Reads a record from a signalized node table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetSignalizedNodeRecord structure
into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.28 **NetWriteSignalizedNode**

Signature int **NetWriteSignalizedNode** (FILE* file,
 const TNetSignalizedNodeRecord* record)

Description Writes a record to a signalized node table.

Argument file – the FILE* pointer for the network data table.
 record – the pointer to the TNetSignalizedNodeRecord structure
 from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.29 **NetReadPhasingPlan**

Signature int **NetReadPhasingPlan** (FILE* file,
 TNetPhasingPlanRecord* record)

Description Reads a record from a phasing plan table.

Argument file – FILE* pointer for the network data table.
 record – pointer to TNetPhasingPlanRecord structure into which
 the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.30 **NetWritePhasingPlan**

Signature int **NetWritePhasingPlan** (FILE* file,
 const TNetPhasingPlanRecord* record)

Description Writes a record to a phasing plan table.

Argument file – the FILE* pointer for the network data table.
 record – the pointer to the TNetPhasingPlanRecord structure from
 which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.31 NetReadTimingPlan

Signature int **NetReadTimingPlan** (FILE* file,
TNetTimingPlanRecord* record)

Description Reads a record from a timing plan table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTimingPlanRecord structure into
which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.32 NetWriteTimingPlan

Signature int **NetWriteTimingPlan** (FILE* file,
const TNetTimingPlanRecord * record)

Description Writes a record to a timing plan table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetTimingPlanRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.33 NetReadDetector

Signature int **NetReadDetector** (FILE* file,
TNetDetectorRecord* record)

Description Reads a record from a detector table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetDetectorRecord structure into
which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.34 NetWriteDetector

Signature int **NetWriteDetector** (FILE* file,
const TNetDetectorRecord* record)

Description Writes a record to a detector table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetDetectorRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.35 NetReadSignalCoordinator

Signature int **NetReadSignalCoordinator** (FILE* file,
TNetSignalCoordinatorRecord* record)

Description Reads a record from a signal coordinator table.

Argument file – The FILE* pointer for the network data table.
record – The pointer to the TNetSignalCoordinatorRecord
structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.36 NetWriteSignalCoordinator

Signature int **NetWriteSignalCoordinator** (FILE* file,
const TNetSignalCoordinatorRecord* record)

Description Writes a record to a signal coordinator table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetSignalCoordinatorRecord
structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.37 NetReadActivityLocation

Signature int **NetReadActivityLocation** (FILE* file,
TNetActivityLocationRecord* record)

Description Reads a record from an activity location table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetActivityLocationRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.38 NetWriteActivityLocation

Signature int **NetWriteActivityLocation** (FILE* file, const
TNetActivityLocationRecord* record)

Description Writes a record to a process link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetActivityLocationRecord structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.39 NetReadProcessLink

Signature int **NetReadProcessLink** (FILE* file,
TNetProcessLinkRecord* record)

Description Reads a record from a process link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetProcessLinkRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.40 NetWriteProcessLink

Signature int **NetWriteProcessLink** (FILE* file,
const TNetProcessLinkRecord* record)

Description Writes a record to a process link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetProcessLinkRecord structure from
which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.1.41 NetReadStudyAreaLink

Signature int **NetReadStudyAreaLink** (FILE* file,
TNetStudyAreaLinkRecord* record)

Description Reads a record from a study area link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetStudyAreaLinkRecord structure
into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

9.1.42 NetWriteStudyAreaLink

Signature int **NetWriteStudyAreaLink** (FILE* file,
const TNetStudyAreaLinkRecord* record)

Description Writes a record to a study area link table.

Argument file – the FILE* pointer for the network data table.
record – the pointer to the TNetStudyAreaLinkRecord structure
from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

9.2 Data Structures

9.2.1 TNetHeader

This structure is used for all of the network table header.

```
typedef struct
{
    /** The field names. */
    INT8 fFields[512];

} TNetHeader;
```

9.2.2 TNetNodeRecord

This structure is used for network node table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The EASTING field. */
    REAL64 fEasting;

    /** The NORTHING field. */
    REAL64 fNorthing;

    /** The ELEVATION field. */
    REAL64 fElevation;

    /** The NOTES field. */
    INT8 fNotes[256];

} TNetNodeRecord;
```

9.2.3 TNetLinkRecord

This structure is used for network link table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;
```

```
/** The NAME field. */
INT8 fName[51];

/** The NODEA field. */
INT32 fNodea;

/** The NODEB field. */
INT32 fNodeb;

/** The PERMLANESA field. */
INT32 fPermlanesa;

/** The PERMLANESB field. */
INT32 fPermlanesb;

/** The LEFTPCKTSA field. */
INT32 fLeftpcktsa;

/** The LEFTPCKTSB field. */
INT32 fLeftpcktsb;

/** The RIGHTPCKTSA field. */
INT32 fRightpcktsa;

/** The RIGHTPCKTSB field. */
INT32 fRightpcktsb;

/** The TWOWAYTURN field. */
INT8 fTwowayturn[2];

/** The LENGTH field. */
REAL64 fLength;

/** The GRADE field. */
REAL64 fGrade;

/** The SETBACKA field. */
REAL64 fSetbacka;

/** The SETBACKB field. */
REAL64 fSetbackb;

/** The CAPACITYA field. */
INT32 fCapacitya;

/** The CAPACITYB field. */
INT32 fCapacityb;

/** The SPEEDLMTA field. */
REAL64 fSpeedlmta;
```

```

/** The SPEEDLMTB field. */
REAL64 fSpeedlmtb;

/** The FREESPDA field. */
REAL64 fFreespda;

/** The FREESPDB field. */
REAL64 fFreespdb;

/** The FUNCTCLASS field. */
INT8 fFunctclass[11];

/** The THRUA field. */
INT32 fThrua;

/** The THRUB field. */
INT32 fThrub;

/** The COLOR field. */
INT32 fColor;

/** The VEHICLE field. */
INT8 fVehicle[101];

/** the NOTES field. */
INT8 fNotes[256];

} TNetLinkRecord;

```

9.2.4 TNetSpeedRecord

This structure is used for network speed table records.

```

typedef struct
{
    /** The LINK field. */
    INT32 fLink;

    /** The NODE field. */
    INT32 fNode;

    /** The SPEEDLMT field. */
    REAL64 fSpeedlmt;

    /** The FREESPD field. */
    REAL64 fFreespd;

    /** The VEHICLE field. */
    INT8 fVehicle[101];
}

```

```
/** The STARTTIME field. */
INT8 fStarttime[9];

/** The ENDTIME field. */
INT8 fEndtime[9];

/** The NOTES field. */
INT8 fNotes[256]

} TNetSpeedRecord;
```

9.2.5 TNetPocketRecord

This structure is used for network pocket lane table records.

```
typedef struct
{

/** The ID field. */
INT32 fId;

/** The NODE field. */
INT32 fNode;

/** The LINK field. */
INT32 fLink;

/** The OFFSET field. */
REAL64 fOffset;

/** The LANE field. */
INT32 fLane;

/** The STYLE field. */
INT8 fStyle[2];

/** The LENGTH field. */
REAL64 fLength;

/** The NOTES field. */
INT8 fNotes[256];

} TNetPocketRecord;
```

9.2.6 TNetLaneUseRecord

This structure is used for network lane use table records.

```
typedef struct
{
    /** The NODE field. */
    INT32 fNode;

    /** The LINK field. */
    INT32 fLink;

    /** The LANE field. */
    INT32 fLane;

    /** The VEHICLE field. */
    INT8 fVehicle[101];

    /** The RESTRICT field. */
    INT8 fRestrict[2];

    /** The STARTTIME field. */
    INT8 fStarttime[9];

    /** The ENDTIME field. */
    INT8 fEndtime[9];

    /** The NOTES field. */
    INT8 fNotes[256];
}
```

9.2.7 TNetParkingRecord

This structure is used for network parking table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The NODE field. */
    INT32 fNode;

    /** The LINK field. */
    INT32 fLink;
```

```

/** The OFFSET field. */
REAL64 fOffset;

/** The STYLE field. */
INT8 fStyle[6];

/** The CAPACITY field. */
INT32 fCapacity;

/** The GENERIC field. */
INT8 fGeneric[2];

/** The VEHICLE field. */
INT8 fVehicle[101];

/** The STARTTIME field. */
INT8 fStarttime[9];

/** The ENDTIME field. */
INT8 fEndtime[9];

/** The NOTES field. */
INT8 fNotes[256];

} TNetParkingRecord;

```

9.2.8 TNetBarrierRecord

This structure is used for network barrier table records.

```

typedef struct
{

/** The ID field. */
INT32 fId;

/** The NODE field. */
INT32 fNode;

/** The LINK field. */
INT32 fLink;

/** The OFFSET field. */
REAL64 fOffset;

/** The LANE field. */
INT32 fLane;

/** The STYLE field. */
INT8 fStyle[11];

```

```
/** The LENGTH field. */
REAL64 fLength;

/** The NOTES field. */
INT8 fNotes[256];

} TNetBarrierRecord;
```

9.2.9 TNetTransitStopRecord

This structure is used for network transit stop table records.

```
typedef struct
{

/** The ID field. */
INT32 fId;

/** The NAME field. */
INT8 fName[51];

/** The NODE field. */
INT32 fNode;

/** The LINK field. */
INT32 fLink;

/** The OFFSET field. */
REAL64 fOffset;

/** The VEHICLE field. */
INT8 fVehicle[101];

/** The STYLE field. */
INT8 fStyle[11];

/** The CAPACITY field. */
INT32 fCapacity;

/** The NOTES field. */
INT8 fNotes[256];

} TNetTransitStopRecord;
```

9.2.10 TNetLaneConnectivityRecord

This structure is used for network lane connectivity table records.

```
typedef struct
{
    /** The NODE field. */
    INT32 fNode;

    /** The INLINK field. */
    INT32 fInlink;

    /** The INLANE field. */
    INT32 fInlane;

    /** The OUTLINK field. */
    INT32 fOutlink;

    /** The OUTLANE field. */
    INT32 fOutlane;

    /** The NOTES field. */
    INT8 fNotes[256];
} TNetLaneConnectivityRecord;
```

9.2.11 TNetTurnProhibitionRecord

This structure is used for network turn prohibition table records.

```
typedef struct
{
    /** The NODE field. */
    INT32 fNode;

    /** The INLINK field. */
    INT32 fInlink;

    /** The OUTLINK field. */
    INT32 fOutlink;

    /** The STARTTIME field. */
    INT8 fStarttime[9];

    /** The ENDTIME field. */
    INT8 fEndtime[9];
} TNetTurnProhibitionRecord;
```

```

/** The NOTES field. */
INT8 fNotes[256];

} TNetTurnProhibitionRecord;

```

9.2.12 TNetUnsignalizedNodeRecord

This structure is used for network unsignalized node table records.

```

typedef struct
{

/** The NODE field. */
INT32 fNode;

/** The INLINK field. */
INT32 fInlink;

/** The SIGN field. */
INT8 fSign[2];

/** The NOTES field. */
INT8 fNotes;

} TNetUnsignalizedNodeRecord;

```

9.2.13 TNetSignalizedNodeRecord

This structure is used for network signalized node table records.

```

typedef struct
{

/** The NODE field. */
INT32 fNode;

/** The TYPE field. */
INT8 fType[2];

/** The PLAN field. */
INT32 fPlan;

/** The OFFSET field. */
REAL64 fOffset;

/** The STARTTIME field. */
INT8 fStarttime[9];

/** The COORDINATR field. */
INT32 fCoordinatr;

```

```
/** The RING field. */
INT8 fRing[2];

/** The ALGORITHM field. */
INT8 fAlgorithm[11];

/** The NOTES field. */
INT8 fNotes[256];

} TNetSignalizedNodeRecord;
```

9.2.14 TNetPhasingPlanRecord

This structure is used for network phasing plan table records.

```
typedef struct
{
    /** The NODE field. */
    INT32 fNode;

    /** The PLAN field. */
    INT32 fPlan;

    /** The PHASE field. */
    INT32 fPhase;

    /** The INLINK field. */
    INT32 fInlink;

    /** The OUTLINK field. */
    INT32 fOutlink;

    /** The PROTECTION field. */
    INT8 fProtection[2];

    /** The DETECTORS field. */
    INT8 fDetectors[51];

    /** The NOTES field. */
    INT8 fNotes[256];

} TNetPhasingPlanRecord;
```

9.2.15 TNetTimingPlanRecord

This structure is used for network timing plan table records.

```
typedef struct
{
    /** The PLAN field. */
    INT32 fPlan;

    /** The PHASE field. */
    INT32 fPhase;

    /** The NEXTPHASES field. */
    INT8 fNextphases[21];

    /** The GREENMIN field. */
    REAL64 fGreenmin;

    /** The GREENMAX field. */
    REAL64 fGreenmax;

    /** The GREENNEXT field. */
    REAL64 fGreennext;

    /** The YELLOW field. */
    REAL64 fYellow;

    /** The REDCLEAR field. */
    REAL64 fRedclear;

    /** The GROUPFIRST field. */
    INT32 fGroupfirst;

    /** The NOTES field. */
    INT8 fNotes[256];
} TNetTimingPlanRecord;
```

9.2.16 TNetDetectorRecord

This structure is used for network detector table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The NODE field. */
    INT32 fNode;

    /** The LINK field. */
    INT32 fLink;

    /** The OFFSET field. */
    REAL64 fOffset;

    /** The LANEBEGIN field. */
    INT32 fLanebegin;

    /** The LANEEND field. */
    INT32 fLaneend;

    /** The LENGTH field. */
    REAL64 fLength;

    /** The STYLE field. */
    INT8 fStyle[11];

    /** The COORDINATR field. */
    INT8 fCoordinatr[51];

    /** The CATEGORY field. */
    INT8 fCategory[11];

    /** The NOTES field. */
    INT8 fNotes[256];
} TNetDetectorRecord;
```

9.2.17 TNetSignalCoordinatorRecord

This structure is used for network signal coordinator table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The TYPE field. */
    INT8 fType[11];

    /** The ALGORITHM field. */
    INT8 fAlgorithm[11];

    /** The NOTES field. */
    INT8 fNotes;

} TNetSignalCoordinatorRecord;
```

9.2.18 TNetActivityLocationRecord

This structure is used for activity location table records.

```
/** Maximum allowed optional user-defined fields in activity
 *  location data.
 */
#define ACTIVITY_MAX_USER 20

typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The NODE field. */
    INT32 fNode;

    /** The LINK field. */
    INT32 fLink;

    /** The OFFSET field. */
    REAL64 fOffset;

    /** The LAYER field. */
    INT8 fLayer[11];
```

```

/** The EASTING field. */
REAL64 fEasting;

/** The NORTHING field. */
REAL64 fNorthing;

/** The ELEVATION field. */
REAL64 fElevation;

/** The number of values in the fUserName and fUser Data arrays.
INT32 fNumberUser;

/** Optional array of user-defined real values. The number of
 * values in the array is variable, but must be the same in each
 * record. The data will typically be related to land use.
 * The optional fields immediately precede the NOTES field.
 */
REAL64 fUserData[ACTIVITY_MAX_USER];

/** The names of the fields in fUser Data. */
INT8 fUserNames[ACTIVITY_MAX_USER] [32];

/** The NOTES field. */
INT8 fNotes[256];

} TNetActivityLocationRecord;

```

9.2.19 TNetProcessLinkRecord

This structure is used for process link table records.

```

typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The FROMID field. */
    INT32 fFromid;

    /** The FROMTYPE field. */
    INT8 fFromtype[11];

    /** The TOID field. */
    INT32 fToid;

    /** The TOTYPE field. */
    INT8 fTotype[11];
}

```

```
/** The DELAY field. */
REAL64 fDelay;

/** The COST field. */
REAL64 fCost;

/** The NOTES field. */
INT8 fNotes[256];

} TNetProcessLinkRecord;
```

9.2.20 TNetStudyAreaLinkRecord

This structure is used for network study area link table records.

```
typedef struct
{
    /** The ID field. */
    INT32 fId;

    /** The BUFFER field. */
    INT8 fBuffer[2];

    /** The NOTES field. */
    INT8 fNotes;

} TNetStudyAreaLinkRecord;
```

10. INDEXING

TRANSIMS data files (particularly the activity, plan, output, and iteration database files) may be very large. Furthermore, the following common operations on these files must be efficient:

- modifying small, randomly scattered records,
- merging modifications back into the original file,
- sorting on several different keys, and
- retrieving specified records.

File indexing provides a mechanism for efficient use of these large files.

TRANSIMS provides a C library that supports accessing files through an associated index. It also incorporates a particular strategy for using this library within the TRANSIMS Framework. This section describes the indexes and the library routines and the way they are used within TRANSIMS.

10.1 Interface Functions

10.1.1 **BTree_Create**

Signature void **BTree_Create** (BTree* tree,
 const char* data_file,
 const char* index_file)

Description Creates a new index; does not add any entries to the index file.

Argument *tree* – the tree to create; assumes *tree* is a valid pointer.
 date_file – the name of the file where the data resides.
 index_file – the name of the index file to create.

Return Value None.

10.1.2 **BTree_Open**

Signature void **BTree_Open** (BTree* tree, const char* index_file)

Description Opens an existing btree index file.

Argument tree – the tree to open; assumes tree is a valid pointer.
index_file – the name of the index file to open.

Return Value None.

10.1.3 **BTree_Close**

Signature void **BTree_Close** (BTree* tree)

Description Closes a btree and releases resources.

Argument tree – the tree to close; the pointer is not freed.

Return Value None.

10.1.4 **BTree_CreateFromFile**

Signature BTree* **BTree_CreateFromFile** (const char* data_file,
const char* index_file, enum act_keys key1,
enum act_keys key2)

Description Creates a btree from a given data file.

Argument data_file – the datafile from which to read entries.
index_file – the index file to which entries will be added.
key1 – the field number of the primary key.
key2 – the field number of the secondary key.

Return Value A new index containing the entries from the data file.

10.1.5 BTREE_ADDFILETOINDEX

Signature void **BTREE_ADDFILETOINDEX** (BTREE* tree, char* data_file)

Description Adds entries in file to tree.

Argument tree – the tree to which entries will be added.
data_file – the data file from which to take entries.

Return Value None.

10.1.6 BTREE_INSERT

Signature void **BTREE_INSERT** (BTREE* tree, BTREEENTRY* entry)

Description Inserts an entry into a btree.

Argument tree – the index to which entries will be added.
entry – the entry to add.

Return Value None.

10.1.7 BTREE_ADDFILENAME

Signature int **BTREE_ADDFILENAME** (BTREE* tree, char* filename)

Description Adds an additional data filename.

Argument tree – the tree to which the filename will be added.
filename – the data file to add.

Return Value The filenumber of the added filename.

10.1.8 BTREE_GETFILENAME

Signature char* **BTREE_GETFILENAME** (BTREE* tree, int i)

Description Converts from the filenumber in a BTREEENTRY to filename.

Argument tree – the tree in which to do the lookup.
i – the filenumber to look up.

Return Value The filename of the corresponding data file, or NULL if there is no such data file.

10.1.9 BTREE_GetFileName

Signature int **BTREE_GetFileName** (BTREE* tree,
const char* filename)

Description Converts from the filename to the filenumber.

Argument tree – the tree in which to do the lookup.
filename – the data filename to look up.

Return Value The filenumber of the corresponding data file, or -1 if there is no such data file.

10.1.10 BTREE_ClearFilename

Signature void **BTREE_ClearFilename** (BTREE* tree)

Description Removes all filenames.

Argument tree – the tree from which to remove filenames.

Return Value None.

10.1.11 BTREE_RenumberFiles

Signature void **BTREE_RenumberFiles**(BTREE* tree, int dest, int src)

Description Renumbers the filenumber in entries of a tree.

Argument tree – the tree in which to do the renumbering.
dest – the new filenumber.
src – the old filenumber, if -1 renumber all entries.

Return Value None.

10.1.12 BTREE_GetDataPointer

Signature `char* BTREE_GetDataPointer (BTREE* tree, BTREEEntry* e)`

Description Gets entry in the data file for entry.

Argument `tree` – the tree in which to do lookup.
`e` – the entry for which to find data.

Return Value A pointer into the mmaped file, or NULL if the data is not found. The pointer is not null-terminating ('\0'). Any changes made through this pointer will be reflected in the data file. This pointer should not be freed.

10.1.13 BTREE_GetDataLine

Signature `char* BTREE_GetDataLine (BTREE* tree, BTREEEntry* e)`

Description Gets entry in the data file for entry.

Argument `tree` – the tree in which to do lookup.
`e` – the entry for which to find data.

Return Value A copy of the data, or NULL if the data is not found. The pointer is null-terminated ('\0'). Any changes made through this pointer will not be reflected in the data file. The caller is responsible for freeing this pointer.

10.1.14 BTREE_FindEntry

Signature `BTREEEntry* BTREE_FindEntry (BTREE* tree, BTREEEntry* e)`

Description Finds an entry in a tree.

Argument `tree` – the tree in which to do the search.
`e` – the entry to find, only needs keys to be set up correctly.

Return Value The complete entry in the tree, or NULL if the entry was not found.

10.1.15 BTREE_VALIDATE

Signature void **BTREE_VALIDATE** (BTREE* tree, const char* from)

Description Validates a tree. Currently, checks for the following:

- the proper order of elements in the tree
- the correct number of entries
- stuff in the valid subtree
 - the valid key types
 - the valid filenumber
 - the valid child pointers

Argument tree – the tree to validate.

from – where called from, used to print message (only if problem found).

Return Value None.

10.1.16 BTREE_DELETEENTRY

Signature void **BTREE_DELETEENTRY** (BTREE* tree, BTREEENTRY* e)

Description Deletes an index entry in a tree. Does not modify any data files.

Argument tree – the tree from which to delete.
e – the entry to delete.

Return Value None.

10.1.17 BTREEIT_CREATE

Signature BTREEIT* **BTREEIT_CREATE** (BTREE* tree)

Description Creates an iterator to a tree.

Argument tree – the tree into which to point.

Return Value An iterator into the tree. This iterator should be destroyed with **BTREEIT_DESTROY** () to free all resources. This iterator is invalid if the tree is modified.

10.1.18 BTREEIT_RESET

Signature void **BTREEIT_RESET** (BTREEIT* *it*)

Description Resets an iterator to point to the first entry of the tree.

Argument *it* – the iterator to reset.

Return Value None.

10.1.19 BTREEIT_ADVANCE

Signature void **BTREEIT_ADVANCE** (BTREEIT* *it*)

Description Advances the iterator to the next entry in the tree.

Argument *it* – the iterator to advance.

Return Value None.

10.1.20 BTREEIT_MOREDATA

Signature int **BTREEIT_MOREDATA** (BTREEIT* *it*)

Description Are we at the end of the index?

Argument *it* – the iterator to check.

Return Value 0 if there are no more entries; non-zero if there are more entries.

10.1.21 BTREEIT_GET

Signature BTREEENTRY* **BTREEIT_GET** (BTREEIT* *it*)

Description Gets the entry to which the iterator points.

Argument *it* – the iterator to query.

Return Value A pointer to the current entry in the tree, or NULL if the iterator is invalid. The entry should not be modified or freed.

10.1.22 BTREEIT_DESTROY

Signature void BTREEIT_Destroy (BTREEIT* it)

Description Destroys an iterator and frees all resources.

Argument it – the iterator to destroy.

Return Value None.

10.1.23 BTREEIT_GETITERATOR

Signature BTREEIT* BTREEIT_GetIterator (BTREE* tree, BTREEENTRY* e)

Description Returns an iterator pointing to an entry in the tree.

Argument tree – the tree in which to find the iterator.

e – the entry to set the iterator to, only needs keys to be set up correctly.

Return Value An iterator that points to e; or NULL if e was not found.

10.1.24 BTREEIT_COMPARE_EQUAL

Signature int BTREEIT_Compare_Equal (BTREEIT* i1, BTREEIT* i2)

Description Compares two iterators.

Argument i1, i2 – iterators to compare.

Return Value 0 if the iterators do not point to the same entry in the tree; non-zero if they do point to the same entry.

10.2 Data Structures

10.2.1 Key

This structure is used to represent the value of a key.

```
typedef union u_key
{
    /** A key can be either an integer or a floating point number.
     */
    int I;
    float f;

} Key;
```

10.2.2 BTeeEntry

This structure is used as an index entry; it holds two keys—the filenumber and offset where the data resides.

```
typedef struct btree_entry_s
{
    /** The primary Key. **/
    Key key1;

    /** The secondary Key. **/
    Key key2;

    /** The number of bytes from the beginning of file. **/
    off_t offset;

    /** The number of the data file. **/
    short file;

    /** The key data types. **/
    char key_type;

    /** Unused. **/
    char pad;

} BTeeEntry;
```

10.2.3 BTreeNode

This structure is used as the node of a btree; it holds up to BTREE_ORDER entries and BTREE_order+1 children.

```
typedef struct btree_node_s
{
    /** The number of keys currently in this node. */
    int keys;

    /** Is this a leaf node? */
    int leaf;

    /** The data to be stored. */
    struct btree_entry key [BTREE_ORDER];

    /** The child pointers. */
    off_t child[BTREE_ORDER+1];

    /** Padding to make node even multiple of page size. */
    char pad[20];
} BTreeNode;
```

10.2.4 BTree

This structure contains information about a btree. It is sized so that it takes up the first page of the btree index file (BTREE_PAGESIZE bytes). One btree can have up to 255 data files, with a combined filename length of 5596 bytes.

```
typedef struct btree_s
{
    /** The index of the root of the tree. */
    off_t root;

    /** The index file. */
    int index_fd;

    /** The start of the node array. */
    struct btree_node* index;

    /** The number of nodes used. */
    size_t size;

    /** The number of nodes allocated. */
    size_t allocated;
```

```

/** The number of entries in the tree. */
size_t entries;

/** The height of the tree. */
size_t height;

/** The field number of key1. */
short key1;

/** The field number of key2. */
short key2;

/** The order of this btree, used as a sanity check. */
short order;

/** The number of data files. */
char num_filenames;

/** The version of the btree file, used as a sanity check. */
char version;

/** The file descriptors for the data files. */
int data_fd[256];

/** The pointers to the mmaped files. */
char* data[256];

/** The offset in the filename array of filenames. */
short filename_off[256];

/** The names of the index files. */
char filename[5596];

} BTREE;

```

10.2.5 BtreeIt

This structure holds a pointer into a btree index.

```

typedef struct btree_it
{
    /** The tree into which this iterator points. */
    BTREE* tree;

    /** The height of the tree. */
    int height;

    /** The level in the tree of the iterator. */
    int level;

```

```
/** The path from the root of the tree to the current
 * position.
 */
off_t* node;

/** The current key number at each level in the path. ***/
size_t* key;

} BTreeIt;
```

10.3 Utility Programs

10.3.1 IndexFilenames

The purpose of this tool is to allow easy inspection and reassignment of the data filenames referred to by an index.

Each index file maintains a directory listing the names of the data files to which its entries refer, and a default UNIX directory path that is prepended to any filenames that do not begin with the character “/”. The directory entries themselves contain pointers into this list of filenames. When a data file is moved, it is more efficient to update the list of filenames than to recreate the index.

This tool can be invoked in either “write” or “read” mode. In write mode, it simply prints the default directory and filenames, one per line, into a file. In read mode, it reads the default directory and filenames from a file and overwrites the current settings in the index file.

Usage:

```
% IndexFilenames <index> <command> <file>
```

Where <index> is the index file to read or modify, <command> is “w” to write the names of the data files to <file> or “r” to read the names of the data files from <file>. The first line of <file> is the default directory, which will be prepended to any data filename that does not begin with a “/” or “.”. For example, to change the name of location of the data files for the local activities household index, the following commands would be needed:

```
% IndexFilenames local.act.hh.idx w names
% vi names # edit names of data files
% IndexFilename local.act.hh.idx r names
```

Example:

This example shows how to update the index *plans.tim.idx* if the data files it refers to are moved from */tmp* to */home/eubank*.

```
gershwin 1> $TRANSIMS_HOME/bin/IndexFilenames plans.tim.idx w names
gershwin 2> cat names
/tmp
plans.1
plans.2
gershwin 3> cat > newnames
/home/eubank
plans.1
plans.2
gershwin 4> $TRANSIMS_HOME/bin/IndexFilenames plans.tim.idx r newnames
```

Troubleshooting:

It is an error to reduce the number of filenames held in an index's directory, since some entries will no longer point to a valid filename. It is not an error to have duplicate filenames, although it may cause inefficient memory use when the index is used.

10.3.2 IndexActivityFile, IndexPlanFile, IndexVehFile, IndexPopulationFile, IndexTravelTimeFile, IndexEventFile

These standalone utilities create index files for the TRANSIMS population, activity, plan, vehicle, travel time, and microsimulation event files. The types of indexes and corresponding suffixes are listed in Table 4. The index files are created in the same directory as the original file.

Usage:

```
$ IndexPopulationFile <population file>
$ IndexActivityFile <activity file>
$ IndexPlanFile <plan file>
$ IndexVehFile <vehicle file>
$ IndexTravelTimeFile <travel time file>
$ IndexEventFile <microsimulation event file>
```

All defined indexes for the files are created. If, for example, the traveler index, *plan_file.trv.idx*, already exists for a plan file but the departure time index, *plan_file.tim.idx*, does not exist, *IndexPlanFile* will create the time index. If neither index exists, both will be created by *IndexPlanFile*.

10.3.3 MergeIndices

The purpose of the *MergeIndices* tool is to merge and update potentially large data files without touching all of the data on disk. For example, a 100 Megabyte plan file can be merged with another 100 Megabyte plan file and the result sorted by both departure time and traveler ID simply by merging and sorting the indexes for each file properly.

For each input index specified on the command line, copy the desired entries from that index into an output index. Only those entries whose primary key has not been seen in a previously processed index are desired. The input indexes are processed from last to first, so this restriction essentially means that entries from indexes specified later on the command line overwrite those specified earlier on the command line.

Usage:

```
% MergeIndices <output-name> <index1> [<index2> [<index3> ... ]]
```

Example:

The following command will merge the indexes for transit driver plans stored in the file *plans.transit*, plans from the first iteration of the Route Planner stored in *plans.pop.1*, and plans from the second iteration of the Route Planner stored in *plans.pop.2*:

```
% MergeIndices out.trv.idx plans.transit.trv.idx plans.pop.1.trv.idx plans.pop.2.trv.idx
```

The output index will be *out.trv.idx*. Assuming all of the transit driver IDs are distinct from other members of the population, *out.trv.idx* will contain all of the transit driver plans, all of the plans from *plans.pop.2*, and plans for all of the travelers in *plans.pop.1* who did not appear in *plans.pop.2*.

The resulting index can be used to create an index sorted by time using the *IndexPlanFile* tool. (Remove any existing *out.tim.idx* first.) Alternatively, the Traffic Microsimulator will create the index sorted by time when it is next run. These indexes can be used directly by the Traffic Microsimulator (or distributed using the *DistributePlans* tool, or viewed using the *PlanFilter* tool) without the need to create an actual file *out* containing all the data for the plan legs. If desired, such a file could be created using the *-d* option of the *PlanFilter* tool.

Troubleshooting:

Only the primary key is used to distinguish entries. Thus, *MergeIndices* works well for plans indexed by traveler ID, but not for plans indexed by departure time. Similarly, if the household ID is used as a key, all travelers in a household should be updated at once.

10.3.4 IndexDefrag

The *IndexDefrag* utility defragments and merges the data files for an index. The entries in an index are written to a new datafile in the order that they appear in the index. The index is modified to use the new data file. For example, if *vehicles.hh.idx* refers to *vehicles1*, and *vehicles2*, then the command

```
% IndexDefrag vehicles.hh.idx vehicles.new
```

will create a new datafile, with the entries from *vehicles1* and *vehicles2* that occur in *vehicles.hh.idx*. The index file *vehicles.hh.idx* will now refer only to file *vehicles.new*.

10.4 Files

Table 3: Indexing library files.

Type	File Name	Description
Binary Files	<i>libTIO.a</i>	The TRANSIMS Interfaces library.
Source Files	<i>btree.h</i>	The <i>Btree</i> and <i>BTreeEntry</i> data structures and interface functions.
	<i>btree.c</i>	The <i>Btree.h</i> interface functions source file.
	<i>btree_it.h</i>	The <i>BtreeIt</i> data structure and interface functions.
	<i>btree_it.c</i>	The <i>btree_it.h</i> interface functions source file.

10.5 Usage

An index must be created for each file to be accessed by the index. Any TRANSIMS component that requires an index file will create it if it does not already exist. Thus, components listed under “Users” in Table 4 create the corresponding index files, as well as the components and utilities listed under “Creators.” Some TRANSIMS components also automatically index some of the files they create. Index files may also be created by standalone utility programs.

Table 4: Indexes used by TRANSIMS components.

Data File Type	Extension	Major, Minor Sort Keys	Creator(s)	User(s)
Population file	.hh.idx	Household ID	Activity Generator/ Regenerator, Collator, IndexPopulationFile	Activity Generator/ Regenerator, Route Planner, Iteration Database
Population file	.hm.idx	Home Location	Activity Generator/ Regenerator Collator, IndexPopulationFile	Iteration Database
Activity file	.hh.idx	Household ID, Person ID	Activity Generator, IndexActivityFile	Route Planner, Iteration Database
Activity file	.trv.idx	Person ID, Household ID	Activity Generator, IndexActivityFile	Traffic Microsimulator, Iteration Database
Plan file	.trv.idx	Traveler ID, Activation Time	Route Planner, IndexPlanFile	Traffic Microsimulator, Iteration Database
Plan file	.tim.idx	Activation Time, Traveler ID	PlanFilter, IndexPlanFile	Traffic Microsimulator
Vehicle file	.veh.idx	Vehicle ID, Household ID	Population Synthesizer, IndexVehicleFile	Activity Generator/ Regenerator, Route Planner, Traffic Microsimulator
Vehicle file	.hh.idx	Household ID, Vehicle ID	IndexVehicleFile	Activity Generator/ Regenerator
Travel Time file	.zn.idx	Zone 1 Number, Zone 2 Number	Activity Generator/ Regenerator, IndexTravelTimeFile, Zone Travel Time Generator	Activity Generator/ Regenerator, Zone Travel Time Generator

Data File Type	Extension	Major, Minor Sort Keys	Creator(s)	User(s)
Event Output	.trv.idx	Traveler ID, Trip ID	IndexEventFile	Iteration Database
Event Output	.loc.idx	Location ID, Traveler ID	IndexEventFile	Iteration Database

Creating an index involves reading each data record in the file, determining the values of the fields to be used as keys, noting the byte offset for the beginning of that record, and inserting an entry into the index (BTree). Each index is given a name derived by adding an extension to the base data file. The extension indicates the major sort key for the index and that the file is an index. For example, .trv.idx indicates that the file is an index whose major sort key is traveler ID. These extensions are defined in the IO library header files.

Indexes are sorted according to the fields used for the major and minor sort keys. If a data file must be accessed in a particular order, for example by traveler ID, it is more efficient to build an index with that field as the major sort key than to create another data file that has been sorted. Thus, the Framework will often expect several different indexes for each data file.

TRANSIMS provides C library routines for creating the indexes used by the Framework, as well as standalone utility programs. Given the name of a data file to index, these routines first determine whether the required index files already exist, with a modification date more recent than that of the data file. If so, nothing is done. Where possible, these routines also create an index by examining other available indexes instead of scanning the entire data file. For example, there are two indexes for plan files—one has traveler ID as a major sort key and departure time as the minor key; the other has the sort keys reversed. Thus, one index can be created from the other without looking at the original data.

The user has access to functions used to compare keys. The current functions compare the primary sort key first. If these are equal, they compare the secondary sort keys. It is possible to specify a *don't care* value for the secondary sort key, which will compare equal to any secondary sort key value.

Indexes may be merged. In this case, entries appearing later in the set of indexes replace earlier entries. None of the data in the original data files needs to be moved to merge the indexes, yet iterating through the merged index will yield the same results as if the data files themselves had been merged and sorted.

Similarly, removing entries from an index makes the corresponding data invisible to users accessing the data file through the index.

After several merge, sort, and filter operations, it becomes difficult to determine the contents of the resulting “notional” file except by using the indexing scheme. To support users who may wish to use other data processing tools, TRANSIMS provides the ability to *defragment* the data pointed to by an index. That is, it provides executables that will create a new file on disk identical to the notional file.

10.6 Examples

```
#include "IO/btree.h"
#include "IO/btree_it.h"

int main(int argc, char* argv[])
{
    char* data_file;
    char* index_file;
    BTTreeEntry entry;
    BTTree* tree;
    BTTreeIt *it;

    index_file = "sample0.idx";
    data_file = "sample1.dat";

    /* Create an index file */
    tree = BTTree_CreateFromFile (data_file,
                                 index_file,
                                 kActivityPerson,
                                 kActivityStartMin);

    /* Add a second data file to the index */
    data_file = "sample2.dat";
    BTTree_AddFileToIndex (tree, data_file);

    /* Delete an entry */
    entry.key1.i = 0;
    entry.key2.f = 0.0;
    entry.key_type = K_IF;
    BTTree_DeleteEntry (tree, &entry);

    /* Use an iterator to examine each entry */
    it = BTTreeIt_Create (tree);
    BTTreeIt_Reset (it);
    while (BTTreeIt_MoreData (it))
    {
        BTTreeEntry* e;
        BTTreeEntry* e2;
        BTTreeIt* it2;
        /* Get the entry for this iterator */
        e = BTTreeIt_Get (it);

        /* Get a second iterator, pointing to the same entry */
        it2 = BTTreeIt_GetIterator (tree, e);
        /* Get the entry for this iterator */
        e2 = BTTreeIt_Get (it2);
        /* Verify that the entries are the same (they should be) */
    }
}
```

```
    if (!BTree_Compare_Equal(e, e2) || !BTreeIt_Compare_Equal
(it, it2))
{
    if (!BTree_Compare_Equal(e, e2))
        printf("Entries differ\n");
    if (!BTreeIt_Compare_Equal (it, it2))
        printf("Iterators differ\n  ");
}
/* Clean up the second iterator */
BTreeIt_Destroy (it2);

/* Advance to the next entry */
BTreeIt_Advance (it);
}
BTreeIt_Destroy (it);

BTree_Close (tree);
free(tree);
return 0;
}
```

11. CONFIGURATION

This section describes the format of configuration files. These files contain the parameters used by the various TRANSIMS software modules.

Configuration files are text files that contain lines of the following types:

- A key followed (optionally) by a value and (optionally) by a comment starting with the pound (#) symbol. The key and the value must be separated by space and/or tab characters.
- A comment line staring with the pound symbol (#).
- A blank line.

11.1 Interface Functions

Functions are available for reading and writing records of a configuration file.

11.1.1 ConfigRead

Signature int **ConfigRead** (FILE* file, TConfigRecord* record)

Description Reads a record from a configuration file.

Argument file – the FILE* pointer for the configuration file.
record – the pointer to the TConfigRecord structure into which the record is read.

Return Value Nonzero if the record was successfully read, or zero if not.

11.1.2 ConfigWrite

Signature int **ConfigWrite** (FILE* file,
const TConfigRecord* record)

Description Writes a record to a configuration file.

Argument file – the FILE* pointer for the configuration file.
record – the pointer to the TConfigRecord structure from which the record is written.

Return Value Nonzero if the record was successfully written, or zero if not.

11.2 Data Structures

11.2.1 TConfigRecord

Structure for configuration file records.

```
typedef struct
{
    /** The key, if the record has one. */
    INT8 fKey[64];

    /** The value, if the record has one. */
    INT8 fValue[256];

    /** The comment, if the record has one. */
    INT8 fComment[512];
} TConfigRecord;
```

11.3 Utility Programs

11.3.1 SetEnv

The *SetEnv* program takes the keys in a configuration file and converts them into UNIX shell environment variables set to the values corresponding to the keys. Its first argument is the name of the UNIX shell, and its second argument is the name of the configuration file; it does not recurse nested configuration files. It is typically used as follows:

```
eval `SetEnv csh default.config`  
eval `SetEnv csh my-run.config`
```

where *default.config* is the default configuration file identified in the configuration file *my-run.config*.

11.4 Files

Table 5: Configuration library files.

Type	File Name	Description
Binary Files	<i>libTIO.a</i>	The TRANSIMS Interfaces library.
Utilities	<i>SetEnv</i>	The environment variable setting utilities.
Source Files	<i>configio.h</i>	The configuration file data structures and interface functions.
	<i>configio.c</i>	The configuration file interface functions source file.

11.5 Configuration File Keys

The configuration file key CONFIG_DEFAULT_FILE specifies the name of a configuration file whose keys and values are to be used in cases where a key is not set in the current configuration file.

11.6 Examples

Figure 1 and Figure 2 give examples of typical configuration and default configuration files, respectively. Note that when keys are duplicated in these files, the value in the non-default file takes precedence.

Figure 1: Example configuration file.

```
CONFIG_DEFAULT_FILE /home/transims/allstr-run/default.config
NET_PROCESS_LINK_TABLE Process_Link.minimal.tbl
ROUTER_MAX_DEGREE 15
CA_BIN /home/projects/transims/config/integration/bin/ARCH.PVM.SUN4SOL2/CA
CA_SIM_STEPS 7200
CA_MASTER_MESSAGE_LEVEL 1
PAR_COMMUNICATION PVM
PAR_SLAVES 1
```

Figure 2: Example default configuration file.

```
#####
GLOBAL PARAMETERS #####
# The width of a lane in meters
# float
GBL_LANE_WIDTH 3.5

# The length of a cell in meters
# float
GBL_CELL_LENGTH 7.5

#####
NETWORK PARAMETERS #####
NET_DIRECTORY /home/transims/allstr-run/network/
NET_NODE_TABLE Node.tbl
NET_LINK_TABLE Link.tbl
NET_POCKET_LANE_TABLE Pocket_Lane.tbl
NET_LANE_USE_TABLE Lane_Use.tbl
NET_SPEED_TABLE Speed.tbl
NET_LANE_CONNECTIVITY_TABLE Lane_Connectivity.tbl
NET_TURN_PROHIBITION_TABLE Turn_Prohibition.tbl
NET_UNSIGNALIZED_NODE_TABLE Unsignalized_Node.tbl
NET_SIGNALIZED_NODE_TABLE Signalized_Node.tbl
NET_PHASENING_PLAN_TABLE Phasing_Plan.tbl
```

```

NET_TIMING_PLAN_TABLE      Timing_Plan.tbl
NET_SIGNAL_COORDINATOR_TABLE Signal_Coordinator.tbl
NET_DETECTOR_TABLE         Detector.tbl
NET_BARRIER_TABLE          Barrier.tbl
NET_PARKING_TABLE          Parking.tbl
NET_TRANSIT_STOP_TABLE     Transit_Stop.tbl
NET_ACTIVITY_LOCATION_TABLE Activity_Location.tbl
NET_PROCESS_LINK_TABLE    Process_Link.tbl
NET_STUDY_AREA_LINKS_TABLE Study_Area_Link.tbl

#####
# SYNTHETIC POPULATION PARAMETERS #####
#####

POP_NUMBER_HH              1000
POP_BASELINE_FILE           /home/transims/allstr-run/output/allstr.basepop
POP_LOCATED_FILE            /home/transims/allstr-run/output/allstr.locpop
POP_STARTING_VEHICLE_ID    100000
POP_STARTING_HH_ID          1
POP_STARTING_PERSON_ID      101

#####
# ACTIVITY GENERATOR PARAMETERS #####
#####

ACT_FULL_OUTPUT              /home/transims/allstr-run/output/allstr.activities
ACT_PARTIAL_OUTPUT            /home/transims/allstr-run/output/allstr.partact
ACT_FEEDBACK_FILE             /home/transims/allstr-run/output/allstr.actfeed
ACT_WORK_LOC_ALPHA            1
ACT_WORK_LOC_BETA             1
ACT_WORK_LOC_GAMMA            1
ACT_TIME_ALPHA                 1
ACT_TIME_BETA                  1
ACT_MODE_ALPHA                 1
ACT_MODE_BETA                  1
ACT_WORK_LOCATION_OPTION      1
ACT_MODE_CHOICE_OPTION        4
ACT_HOME_HEADER                HOME
ACT_WORK_HEADER                 WORK
ACT_ACCESS_HEADER                ACCESS

#####
# OUTPUT PARAMETERS #####
#####

OUT_DIRECTORY                  /home/transims/allstr-run/output

OUT_SNAPSHOT_NAME_1           allstr.snapshot
OUT_SNAPSHOT_BEGIN_TIME_1      0
OUT_SNAPSHOT_END_TIME_1        86400
OUT_SNAPSHOT_TIME_STEP_1       1
OUT_SNAPSHOT_EASTING_MIN_1     1
OUT_SNAPSHOT_EASTING_MAX_1     1000000
OUT_SNAPSHOT_NORTHING_MIN_1    1
OUT_SNAPSHOT_NORTHING_MAX_1    1000000
OUT_SNAPSHOT_NODES_1           /home/transims/allstr-run/data/allstr.nodes
OUT_SNAPSHOT_LINKS_1            /home/transims/allstr-run/data/allstr.links
OUT_SNAPSHOT_SUPPRESS_1         OUT_SNAPSHOT_SUPPRESS_1
OUT_SNAPSHOT_FILTER_1           OUT_SNAPSHOT_FILTER_1

OUT_EVENT_NAME_1                allstr.event
OUT_EVENT_BEGIN_TIME_1          0
OUT_EVENT_END_TIME_1             86400
OUT_EVENT_TIME_STEP_1            1
OUT_EVENT_EASTING_MIN_1          1
OUT_EVENT_EASTING_MAX_1          1000000
OUT_EVENT_NORTHING_MIN_1         1
OUT_EVENT_NORTHING_MAX_1         1000000
OUT_EVENT_NODES_1                /home/transims/allstr-run/data/allstr.nodes
OUT_EVENT_LINKS_1                  /home/transims/allstr-run/data/allstr.links
OUT_EVENT_SUPPRESS_1               OUT_EVENT_SUPPRESS_1
OUT_EVENT_FILTER_1                 OUT_EVENT_FILTER_1

OUT_SUMMARY_NAME_1                allstr.summary

```

```

OUT_SUMMARY_BEGIN_TIME_1      0
OUT_SUMMARY_END_TIME_1       86400
OUT_SUMMARY_TIME_STEP_1       900
OUT_SUMMARY_SAMPLE_TIME_1      60
OUT_SUMMARY_BOX_LENGTH_1       150
OUT_SUMMARY_EASTING_MIN_1      1
OUT_SUMMARY_EASTING_MAX_1      1000000
OUT_SUMMARY_NORTHING_MIN_1      1
OUT_SUMMARY_NORTHING_MAX_1      1000000
OUT_SUMMARY_NODES_1           /home/transims/allstr-run/data/allstr.nodes
OUT_SUMMARY_LINKS_1            /home/transims/allstr-run/data/allstr.links
OUT_SUMMARY_SUPPRESS_1
OUT_SUMMARY_FILTER_1

##### SIMULATION PARAMETERS #####
# see IO/log.h for possible levels
CA_SLAVE_MESSAGE_LEVEL      0
CA_MASTER_MESSAGE_LEVEL      0

# name of executable (used by Msim.pl)
CA_BIN CA

# the max number of occupants of a bus
# int > 1
CA_BUS_CAPACITY      50

# the number of cells a bus occupies in a jam
# float > 0.0
CA_BUS_LENGTH        2.0

# the acceleration of a car, bus, etc.
# (in cells per timestep per timestep)
# float > 0.0
CA_MAXIMUM_ACCELERATION    0.4
CA_BUS_MAXIMUM_ACCELERATION 0.1

# the maximum speed of a car, bus, etc.
# (in cells per timestep)
# float > 0.0
CA_MAXIMUM_SPEED        4.5
CA_BUS_MAXIMUM_SPEED      2.5

# If nonzero, no attempt will be made to read in transit vehicles
# and transit passengers will not be simulated.
# int(?)
CA_NO_TRANSIT        1

# Some time after a vehicle becomes off plan, it will exit the simulation.
# the probability that a vehicle with speed >= 1 will decelerate by 1
# (also an increment added to the speed limit on a link)
# in the discrete version (not compiled with -DCONTINUOUS)
# float > 0 and < 1
CA_DECELERATION_PROBABILITY 0.2

# use to compute the number of cells that must be vacant in an acceptable gap
# (acceptable gap is speed of oncoming vehicle * Velocity Factor)
# float (> 1.0 ? )
CA_GAP_VELOCITY_FACTOR      3.0

# Probability of proceeding when interfering gap is not acceptable
# in cases of links with competing stop/yield signs
# float > 0 and < 1
CA_IGNORE_GAP_PROBABILITY   0.66

# The number of vehicles which can be buffered in each
# of an intersection's queues (One queue for each lane of each incoming link)
# int > 1
CA_INTERSECTION_CAPACITY     10

# Vehicles take at least this many timesteps to traverse an intersection

```

```

# int >= 0
CA_INTERSECTION_WAIT_TIME      1

# Can't change lanes if random variable drawn on each timestep for each vehicle
# is less than this
# float > 0 and < 1
CA_LANE_CHANGE_PROBABILITY     0.99

# number of cells ahead to look for deciding which lane is best upon entering a link
# int >= 0
CA_LOOK_AHEAD_CELLS           35

# If vehicle has not moved for this many timesteps,
# it becomes off-plan and chooses a different destination link, if possible.
# int >= 0
CA_MAX_WAITING_SECONDS        600

# The exit time is the minimum of the expected arrival time at the destination
# and the current time + OFF_PLAN_EXIT_TIME
# int >= 0
CA_OFF_PLAN_EXIT_TIME          1

# Determines, in a complicated way, whether lane changes for the
# sake of following a plan need to be considered
# int >= 0
CA_PLAN_FOLLOWING_CELLS       70

# specify start time for simulation
# int
CA_SIM_START_HOUR              0
CA_SIM_START_MINUTE             0
CA_SIM_START_SECOND              0

# number of timesteps to simulate
# int >= 0
CA_SIM_STEPS                   3600

# send map of locations of all accessories to all slaves
CA_BROADCAST_ACC_CPN_MAP        0

# migrate travelers by broadcasting them
CA_BROADCAST_TRAVELERS          1

# number of time-steps to be executed before slaves synchronize with master
CA_SEQUENCE_LENGTH                1

# Initialize the random seed
# seed48 is called with a pointer to the first element of an array
# of these 3 unsigned shorts
# unsigned short
CA_RANDOM_SEED1                 1
CA_RANDOM_SEED2                 2
CA_RANDOM_SEED3                 3

# Use the cached binary representation of the network database
# in the file specified by CA_NETWORK_FILE
# int
CA_USE_NETWORK_CACHE             0
# string
# CA_NETWORK_FILE

# The following delays model just the time it takes to walk up the steps or
# through the doors or whatever. They have nothing to do with the
# time spent waiting in the queue.

# The mean number of seconds it takes a traveler to board a transit vehicle.
# float >= 0.0
CA_ENTER_TRANSIT_DELAY            1.6

# The mean number of seconds it takes to disembark.
# float >= 0.0

```

```

CA_EXIT_TRANSIT_DELAY 1.8

# The number of seconds after a vehicle reaches the stop before
# passengers can start boarding
CA_TRANSIT_INITIAL_WAIT 5

# Name of a file containing TRANSIMS format vehicle information
# (locations, type, etc.)
CA_VEHICLE_FILE /home/transims/allstr-run/output/allstr.vehicles

CA_USE_PARTITIONED_ROUTE_FILES 0

CA_LATE_BOUNDARY_RECEPTION 1
CA_PARALLEL_LOG 0

CA_PARALLEL_IO_TEST_MODE 0
CA_PARALLEL_IO_TEST_INTERVAL 30

CA_OUTPUT_BUFFER_COUNT 32

CA_RTM_SAMPLE_INTERVAL 0

##### TRANSIT PARAMETERS #####
# Name of a file containing TRANSIMS format transit route information
# (list of stops for each route)
# string
TRANSIT_ROUTE_FILE /home/transims/allstr-run/data/allstr.routes

# Name of a file containing TRANSIMS format transit schedule information
# (list of arrival time for each vehicle at each stop)
# string
TRANSIT_SCHEDULE_FILE /home/transims/allstr-run/data/allstr.schedules

##### PLAN PARAMETERS #####
# Name of a file containing TRANSIMS format legs
# string
PLAN_FILE /home/transims/allstr-run/output/allstr.plans

##### ROUTER PARAMETERS #####
ROUTER_OUTPUT_PLAN_FILE /home/transims/allstr-run/output/allstr.plans
ROUTER_ACTIVITY_FILE /home/transims/allstr-run/output/allstr.activities
ROUTER_VEHICLE_FILE /home/transims/allstr-run/output/allstr.vehicles
ROUTER_MODE_MAP_FILE /home/transims/allstr-run/data/allstr.modes

ROUTER_MAXNFA_SIZE 5
ROUTER_MAX_DEGREE 15
ROUTER_INTERNAL_PLAN_SIZE 400
ROUTER_VERBOSE 2

# If length < corr_thresh * dist, adjust the length
# float
ROUTER_CORR 0.0

# ??
# float
ROUTER_OVERDO 3.0

# Backdating time of travel information ??
# int
ROUTER_ZERO_BACKD 0

##### LOGGING PARAMETERS #####
LOG_LOG_CONFIG 0
LOG_LOAD_NETWORK 1
LOG_PARTITIONING 1
LOG_DISTRIBUTION 1

```

```

LOG_RUNTIMEMONITOR      0
LOG_CONTROL             0
LOG_TIMING              1
LOG_BOUNDARIES          0
LOG_ROUTING             1
LOG_ROUTING_DETAIL      1
LOG_TIMESTEP             1
LOG_TIMESTEP_DETAIL      1
LOG_PARALLEL             0
LOG_VEHICLES             1
LOG_MIGRATION            1
LOG_MIGRATION_DETAIL      1
LOG_TRANSIT              1
LOG_EMISSIONS             1
LOG_IO_DETAIL             0

##### VISUALIZER PARAMETERS #####
# int, will be single buffered if non-zero
VIS_SINGLE_BUFFERED     0

# Name of a file containing batch commands (unused)
# string
VIS_BATCH_FILE

# The length of a box in meters
# float
VIS_BOX_LENGTH           150.0

##### PARTITIONING PARAMETERS #####
PAR_PVM_ROOT             /sw/Cvol/pvm3
PAR_PVM_ARCH              SUN4SOL2
PAR_PVM_WAIT_FOR_DEAMON    20

PAR_MPI_ROOT              /sw/Cvol/mpich
PAR_MPI_ARCH              solaris
PAR_MPI_DEVICE             ch_p4

PAR_MIN_CELLS_TO_SPLIT     10
PAR_SLAVES                  2

# if 1, use orthogonal bisection to distribute the network
# otherwise, use the METIS graph partitioning library
# int
PAR_USE_METIS_PARTITION     1
PAR_USE_OB_PARTITION        0

PAR_PARTITION_FILE          /tmp/partition
PAR_SAVE_PARTITION          0

# if 0 use (number of lanes) for edge weight, (length * number of lanes) for edge penalty
#       and 0 for node weights in the partitioning algorithm
# otherwise, use the file named in RTM_FEEDBACK_FILE and RTM_PENALTY_FACTOR.
# int
PAR_USE_RTM_FEEDBACK        0

# Filename for edge and node weights for partitioning
# File format is lines of the form:
# 0 ID Weight
# 1 ID Weight Penalty
# The first line sets a node weight
# the second line sets an edge weight: if penalty is -1, use current value *
RTM_PENALTY_FACTOR          otherwise use Penalty * RTM_PENALTY_FACTOR
# string
PAR_RTM_FEEDBACK_FILE        /tmp/rtm

# See above for RTM_FEEDBACK_FILE
# float > 0.0
PAR_RTM_PENALTY_FACTOR       100.0

```

```
PAR_REPORT_OUTGOING_LINK_TIME_ONLY      1
#####
# Selector Parameters #####
#
# Only travelers whose (actual - expected) / expected
# is greater than this will be affected by any operations
# float > 0
SEL_FRUSTRATION_THRESH 1.5

# Fraction of travelers to select for
# just rerouting
# reassigning activities
# choosing a new mode preference
# changing the time of activities
# float, >= 0 and <= 1
SEL_REROUTE_FRAC 0.1
SEL_REASSIGN_FRAC 0.1
SEL_REMOTE_MODE_FRAC 0.1
SEL_RETIMING_FRAC 0.1

# Name of files in which to place traveler ids
# selected for each of the possible changes
# string
SEL_REROUTE_FILE
SEL_REMOTE_MODE_FILE
SEL_RETIMING_FILE
SEL_REASSIGN_FILE

# =====
# Local Variables:
# tab-width:4
# End:
# =====
```

12. LOGGING

The TRANSIMS logging interface is to be used for the logging output of all applications that will be part of the TRANSIMS suite of software modules and will be integrated into the development environment. Using a single interface allows the standardization of logging messages.

12.1 Interface Functions

Each logging message is associated with a module passed in the parameter `theSubSystem`. There are predefined modules for most subsystems in TRANSIMS (see *IO/log.h* for a list.)

There are four different message levels that are passed in the parameter `theMessageLevel`:

- 1) `MSG_PRINT` – a normal informative message. It does NOT describe a warning or an error.
- 2) `MSG_WARNING` – a warning that may need user attention, but is most likely not to corrupt the application results.
- 3) `MSG_SEVERE_WARNING` – a warning that does not require the user to shut down the application but will most likely result in corrupted output.
- 4) `MSG_ERROR` – an actual error message that results in immediate termination of the program.

The parameter `Format` contains the actual message. It is interpreted as a C-style `printf(1)` format string that permits the passing of additional parameters after the format string. There is no need to terminate the format string with a newline character, since that will be automatically added.

Notes:

- 1) Do not try to bypass the interface because this may result in messages getting lost.
- 2) Refrain from using the strings `ERROR` or `WARNING` (or any other pattern listed in the DEFINES-Reserved String Pattern section of the *log.h* file) in your messages. The interface will add appropriate strings to your messages so that they can be identified.
- 3) Choose the message level with care since “harmless” levels such as `MSG_PRINT` or `MSG_WARNING` may be deactivated when the application is run in production mode. Really important messages should be of type `MSG_SEVERE_WARNING` or `MSG_ERROR`.

- 4) Do not make any assumption about where the logging output will end up. The default will be standard output, but it may also be redirected to a file.

12.1.1 cMessage

Signature void **cMessage**(enum TSubsystem theSubSystem,
enum TMessageLevel theMessageLevel,
const char* Format, . . .)

Description Writes a message using the logging system. See above for more detailed description.

Argument theSubSystem – an enumeration for the subsystem that produces the message.
theMessageLevel – one of four levels described above.
Format – a string describing the message format.
. . . – any additional parameters that may be needed.

Return Value None.

12.2 Files

Table 6: Logging library files.

Type	File Name	Description
Binary Files	<i>libTIO.a</i>	The TRANSIMS Interfaces library.
Source Files	<i>log.c</i>	The source file the logging functions.
	<i>log.h</i>	The header file for logging functions.

12.3 Examples

```
cMessage (SUB_CA, MSG_WARNING, "More vehicle (%d) than expected (%d)",  
NrOfVehicle, NrOfExpectedVehicles;
```

Volume Five: Index

Activities data structures, 21
Activities interface functions, 9
ActivityData, 21
ActivityTimeSpec, 21
Binary files, 36, 40, 132, 137, 146
BTree, 125, 127
btree.c, 132
btree.h, 132
BTree_AddFilename, 120
BTree_AddFileToIndex, 120
BTree_ClearFilename, 121
BTree_Close, 119
BTree_Create, 118
BTree_CreateFromFile, 119
BTree_DeleteEntry, 123
BTree_FindEntry, 122
BTree_GetDataLine, 122
BTree_GetDataPointer, 122
BTree_GetFilename, 120
BTree_GetFileNumber, 121
BTree_Insert, 120
btree_it.c, 132
btree_it.h, 132
BTree_Open, 119
BTree_RenumberFiles, 121
BTree_Validate, 123
BTreeEntry, 126
BtreeIt, 128
BTreeIt_Advance, 124
BTreeIt_Compare_Equal, 125
BTreeIt_Create, 123
BTreeIt_Destroy, 125
BTreeIt_Get, 124
BTreeIt_GetIterator, 125
BTreeIt_MoreData, 124
BTreeIt_Reset, 124
BTreeNode, 127
cMessage, 146
configio.c, 137
configio.h, 137
ConfigRead, 136
Configuration data structures, 137
Configuration examples, 138
Configuration files, 137
Configuration interface functions, 136
Configuration utility programs, 137
ConfigWrite, 136
CreateActivityIndex, 13
CreateDoublePopulationIndex, 5
CreateEventFileIndex, 74
CreateFeedbackIndex, 20
CreatePopIndexFromFile, 6
CreatePopulationIndex, 2
CreateTravelTimesIndex, 20
DefragmentPlanFiles, 45
Framework, 118
GetCurrentData, 52
getCurrentLeg, 43
getLegDepartTime, 44
getLegLegId, 45
getLegMode, 45
getLegStartAccessoryId, 44
getLegStartAccessoryType, 44
getLegTravelerId, 43
getLegTripId, 44
getModeEntryFromFile, 20
getModeWeightEntryFromData, 19
getModeWeightEntryFromFile, 19
getNextActivity, 9
getNextHousehold, 10
getNextLeg, 41
getNextSyntheticHH, 1
getNextTimeTableEntry, 12
getNextTransitRouteData, 85
getNextTransitScheduleData, 85
getNextTransitZoneData, 86
getNextTripTableEntry, 12
getNextVehicle, 32
getSurveyActivity, 14
getSurveyWeightFromData, 14
getSurveyWeightFromFile, 14
getSyntheticHHFromString, 3
getSyntheticHouseholdFromIndex, 4
getSyntheticPopDemographicHeaders, 4
getTravelTimeEntryFromData, 15
getTravelTimeEntryFromFile, 15
getTreeEntryFromData, 17
getTreeEntryFromFile, 16
getTripTableDimensions, 11
getZoneEntryFromData, 18
getZoneEntryFromFile, 18
getZoneHeaderFromFile, 17
IndexActivityFile, 130
IndexDefrag, 131

IndexFilenames, 129
Indexing data structures, 126
Indexing examples, 134
Indexing files, 132
Indexing interface functions, 118
Indexing usage, 132
Indexing utility programs, 129
IndexPlanFile, 130, 131
IndexPopulationFile, 130
IndexTravelFile, 130
IndexVehFile, 130
ITDB, 59
ITDB_Add, 51
ITDB_AddV, 52
ITDB_ArrayToString, 58
ITDB_Close, 50
ITDB_Create, 49
ITDB_CreateV, 50
ITDB_CurrentIteration, 51
ITDB_FieldNameToNumber, 55
ITDB_FieldNumberToName, 55
ITDB_GetCurrentField, 54
ITDB_GetCurrentString, 52
ITDB_GetData, 53
ITDB_GetField, 54
ITDB_GetFirstField, 54
ITDB_GetLastField, 55
ITDB_GetString, 53
ITDB_GetTotalString, 53
ITDB_It, 60
ITDB_ItAdvance, 57
ITDB_ItCreate, 56
ITDB_ItCreateRecord, 56
ITDB_ItDestroy, 56
ITDB_ItGetData, 57
ITDB_ItGetString, 57
ITDB_ItMoreData, 57
ITDB_ItReset, 56
ITDB_NewIteration, 51
ITDB_Open, 50
ITDB_StringToArray, 57
Iteration Database data structures, 59
Iteration Database interface functions, 49
Key, 126
LegData, 45, 47
libTIO.a, 36, 40, 132, 137, 146
log.c, 146
log.h, 146
Logging examples, 146
Logging files, 146
Logging interface functions, 145
MergeIndices, 130, 131
moreActivities, 9
moreLegs, 41
moreModeEntries, 19
moreModeWeightEntries, 18
moreSurveyActivities, 13
moreSyntheticHH, 1
moreTimeTableEntries, 12
moreTransitData, 84
moreTravelTimes, 15
moreTreeEntries, 16
moreTripTableEntries, 11
moreVehicles, 31
moreZoneEntries, 17
NetReadActivityLocation, 101
NetReadActivityLocationHeader, 90
NetReadBarrier, 94
NetReadDetector, 99
NetReadHeader, 89
NetReadLaneConnectivity, 95
NetReadLaneUse, 93
NetReadLink, 91
NetReadNode, 90
NetReadParking, 93
NetReadPhasingPlan, 98
NetReadPocket, 92
NetReadProcessLink, 101
NetReadSignalCoordinator, 100
NetReadSignalizedNode, 97
NetReadSpeed, 91
NetReadStudyAreaLink, 102
NetReadTimingPlan, 99
NetReadTransitStop, 95
NetReadTurnProhibition, 96
NetReadUnsignalizedNode, 97
NetSkipHeader, 89
Network data structures, 103
Network interface functions, 89
NetWriteActivityLocation, 101
NetWriteBarrier, 94
NetWriteDetector, 100
NetWriteHeader, 89
NetWriteLaneConnectivity, 96
NetWriteLaneUse, 93
NetWriteLink, 91
NetWriteNode, 90
NetWriteParking, 94
NetWritePhasingPlan, 98
NetWritePocket, 92
NetWriteProcessLink, 102
NetWriteSignalCoordinator, 100

NetWriteSignalizedNode, 98
NetWriteSpeed, 92
NetWriteStudyAreaLink, 102
NetWriteTimingPlan, 99
NetWriteTransitStop, 95
NetWriteTurnProhibition, 96
NetWriteUnsignalizedNode, 97
OutHeaderHasField, 62
OutReadHeader, 61
OutReadIntersectionEvolution, 67
OutReadIntersectionEvolutionHeader, 66
OutReadLinkEnergySummary, 74
OutReadLinkEnergySummaryHeader, 73
OutReadLinkSpaceSummary, 71
OutReadLinkSpaceSummaryHeader, 70
OutReadLinkSpecification, 63
OutReadLinkTimeSummary, 70
OutReadLinkTimeSummaryHeader, 69
OutReadLinkVelocitySummary, 72
OutReadLinkVelocitySummaryHeader, 72
OutReadNodeSpecification, 62
OutReadTrafficControlEvolution, 68
OutReadTrafficControlEvolutionHeader, 68
OutReadTravelerEvent, 64
OutReadTravelerEventFromString, 64
OutReadTravelerEventHeader, 63
OutReadVehicleEvolution, 66
OutReadVehicleEvolutionHeader, 65
OutSkipHeader, 61
OutWriteHeader, 61
OutWriteIntersectionEvolution, 67
OutWriteIntersectionEvolutionHeader, 67
OutWriteLinkEnergySummary, 74
OutWriteLinkEnergySummaryHeader, 73
OutWriteLinkSpaceSummary, 71
OutWriteLinkSpaceSummaryHeader, 71
OutWriteLinkSpecification, 63
OutWriteLinkTimeSummary, 70
OutWriteLinkTimeSummaryHeader, 69
OutWriteLinkVelocitySummary, 73
OutWriteLinkVelocitySummaryHeader, 72
OutWriteNodeSpecification, 62
OutWriteTrafficControlEvolution, 69
OutWriteTrafficControlEvolutionHeader, 68
OutWriteTravelerEvent, 65
OutWriteTravelerEventHeader, 64
OutWriteVehicleEvolution, 66
OutWriteVehicleEvolutionHeader, 65
parseBufferedLegRecord, 43
Plan data structures, 47
Plan interface functions, 41
readLegRecord, 42
readLegRecordFromString, 42
readSurveyActivityHeader, 13
ReverseIndex, 46
Route Planner, 41, 131
SetEnv, 137
Simulation Output data structures, 75
Simulation Output interface functions, 61
Source files, 36, 40, 132, 137, 146
Synthetic population data structures, 7
Synthetic population interface functions, 1
SyntheticHHDData, 7
SyntheticPersonData, 7
TConfigRecord, 136, 137
TFeedbackEntry, 27
TModeEntry, 30
TModeWeightEntry, 29
TNetActivityLocationRecord, 115
TNetBarrierRecord, 108
TNetDetectorRecord, 114
TNetHeader, 103
TNetLaneConnectivityRecord, 110
TNetLaneUseRecord, 107
TNetLinkRecord, 103
TNetNodeRecord, 103
TNetParkingRecord, 107
TNetPhasingPlanRecord, 112
TNetPocketRecord, 106
TNetProcessLinkRecord, 116
TNetSignalCoordinatorRecord, 115
TNetSignalizedNodeRecord, 111
TNetSpeedRecord, 105
TNetStudyAreaLinkRecord, 117
TNetTimingPlanRecord, 113
TNetTransitStopRecord, 109
TNetTurnProhibitionRecord, 110
TNetUnsignalizedNodeRecord, 111
TOutHeader, 75
TOutIntersectionEvolutionRecord, 78
TOutLinkEnergySummaryRecord, 82
TOutLinkSpaceSummaryRecord, 81
TOutLinkSpecificationRecord, 75
TOutLinkTimeSummaryRecord, 69, 80
TOutLinkVelocitySummaryRecord, 81
TOutNodeSpecificationRecord, 75
TOutTrafficControlEvolutionRecord, 79
TOutTravelerEventRecord, 75
TOutVehicleEvolutionRecord, 77
Traffic Microsimulator, 41, 131
TRANSIMS Interfaces library, 36, 40, 132, 137, 146

- Transit data structures, 87
Transit interface functions, 84
TransitRouteData, 87
TransitScheduleData, 88
TransitStopData, 87
TransitZoneData, 88
TSurveyActivityEntry, 24
TTimeTableEntry, 24
TTravelTimeEntry, 15, 26
TTreeEntry, 27
TTripTableEntry, 24
TVehDataHeader, 34, 35
TVehHeader, 39
TVehPrototypeData, 39
TZoneEntry, 28
TZoneHeader, 28
VehDataReadHeader, 32
VehDataSkipHeader, 33
VehDataWriteDefaultHeader, 33
VehDataWriteHeader, 33
Vehicle data structures, 34
Vehicle interface functions, 31
Vehicle Prototypes data structures, 39
Vehicle Prototypes interface functions, 37
VehicleData, 34
vehio.c, 36
vehio.h, 36
vehprotoio.c, 40
vehprotoio.h, 40
VehReadHeader, 37
VehReadPrototype, 38
VehSkipHeader, 38
VehWriteDefaultHeader, 37
VehWriteHeader, 37
VehWritePrototype, 38
writeActivity, 10
writeHousehold, 11
writeLeg, 42
writeLegRecord, 43
writeSyntheticHH, 3
writeSyntheticPopHeader, 2
writeTransitRouteData, 85
writeTransitScheduleData, 86
writeTransitZoneData, 86
writeTravelTimeEntry, 16
writeVehicle, 32